

OPERATOR'S MANUAL

D12

This operator's manual is also available in the following languages:

GER

Diese Betriebsanleitung ist auch auf Deutsch erhältlich.

Ein Bestellcoupon ist am Ende der Betriebsanleitung zu finden.

DAN

Denne instruktionsbog kan bestilles på dansk.

Bestillingskupon findes i slutningen af instruktionsbogen.

FRE

Ce manuel d'instructions peut être commandé en français.

Vous trouverez un bon de commande à la fin du manuel d'instructions.

FIN

Tämä ohjekirjan voi tilata myös suomenkielisenä.

Tilauskuponki on ohjekirjan lopussa.

SPA

Este libro de instrucciones puede solicitarse en español.

El cupón de pedido se encuentra al final del libro.

POR

Este manual de instruções pode ser encomendado em português.

O talão de requerimento encontra-se no fim do manual.

SWE

Den här instruktionsboken kan beställas på svenska.

Beställningskupong finns i slutet av instruktionsboken.

GRE

Αυτό το εγχειρίδιο χρήσης διατίθεται στην αγγλική γλώσσα.

Για να παραγγείλετε ένα αντίτυπο, συμπληρώστε τη φόρμα που βρίσκεται στο τέλος αυτού του εγχειριδίου χρήσης.

ITA

Questo manuale d'istruzioni può essere ordinato in lingua italiana.

Il tagliando per l'ordinazione è riportato alla fine del manuale.

RUS

Данное руководство оператора имеется на русском языках.

Для получения инструкции на нужном языке заполните форму в конце инструкции.

DUT

Dit instructieboek kan worden besteld in het Nederlands.

De bestelcoupon vindt u achter in het instructieboek

TUR

Bu kullanýcý el kitabý Türkçe dillerinde mevcuttur.

Birñüşhasýný sipariş etmek için kullanýcý el kitabýnýñ sonundaki formu doldurun.

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



Welcome aboard

Volvo Penta marine engines are used all over the world. They are used in all possible operating conditions for professional as well as leisure purposes. That's not surprising.

After 100 years as an engine manufacturer the Volvo Penta name has become a symbol of reliability, technical innovation, top of the range performance and long service life. We also believe that this is what you demand and expect of your Volvo Penta engine.

We would like you to read this operator's manual thoroughly and consider the advice we give on operation and maintenance before your maiden voyage so that you will be ensured of fulfilling your expectations. Please pay attention to the safety instructions contained in the manual.

As owner of a Volvo Penta marine engine, we would also like to welcome you to a worldwide network of dealers and service workshops to assist you with technical advice, service requirements and replacement parts. Please contact your nearest authorized Volvo Penta dealer for assistance.

We also invite you to visit our home page on the Internet at www.volvopenta.com

With warm regards

AB VOLVO PENTA

Contents

Safety information	3	Stopping the engine	50
General information	3	Stop	50
Boat trips	4	Cold weather precautions.....	51
Care and maintenance	6	Laying up	51
Introduction	8	Maintenance schedule	52
Running in	8	Maintenance	54
Fuel and oils	8	Engine, general	54
Certified engines	9	Lubrication system	57
Warranty information	9	Freshwater system	61
Identification number	10	Seawater system	66
Presentation	11	Fuel system	70
Technical description	11	Electrical system	76
Orientation	12	Reverse gear	81
Instruments	13	Accessories	83
Instruments.....	13	Laying up/Launching	84
Ignition lock.....	13	Inhibiting	84
Start/stop panel	13	Bringing out of storage	85
Alarm display (optional extra)	14	In case of emergency	86
EVC control panel.....	17	Starting with auxiliary batteries	86
EVC system tachometer.....	18	Emergency shifting.....	87
EVC system display (optional extra).....	27	Fault-tracing.....	88
Controls	35	Diagnostic function	89
Single lever control	35	Fault register	92
Two lever control.....	37	Technical data	100
Starting the engine	38	Engine	100
Before starting	38	Reverse gear	102
General information about starting	38		
Starting method	39		
Operation	41		
Reading instruments	41		
Alarm	42		
Cruising speed	42		
Synchronising engine speed	43		
Changing the helm station.....	43		
Operation.....	45		
Low speed	46		
Trolling	47		
Propeller shaft brake	48		
Extra equipment	49		

© 2006 AB VOLVO PENTA

We reserve the right to make modifications without prior notice. Printed on environmentally compatible paper.
(Cover: Department of transport (shipping), license 9809095)

Safety information

Read this chapter very carefully. It has to do with your safety. This describes how safety information is presented in the instruction book and on the product. It also gives you an introduction to the basic safety rules for using and looking after the engine.

Check that you have received the correct instruction book before you read on. If not, please contact your Volvo Penta dealer.



Incorrect operation can lead to personal injury and damage to products or property. So read the instruction book through very carefully before you start the engine or do any maintenance or service work. If there is still something which is unclear or if you feel unsure about it, please contact your Volvo Penta dealer for assistance.

⚠ This symbol is used in the instruction book and on the product, to call your attention to the fact that this is safety information. Always read such information very carefully.

Safety texts in the instruction book have the following order of priority:

⚠ WARNING! Warns for the risk of personal injury, major damage to product or property, or serious malfunctions if the instruction is ignored.

⚠ IMPORTANT! Is used to call attention to things which could cause damage or malfunctions to product or property.

NOTE! Is used to call attention to important information, to facilitate work processes or operation.



This symbol is used on our products in some cases and refers to important information in the instruction book. Make sure that warning and information symbols on the engine are clearly visible and legible. Replace symbols which have been damaged or painted over.

Safety advice for boat operation

Your new boat

Read the instruction books and other information carefully, which came with your new boat. Learn to handle the engine, controls and other equipment in a safe and correct manner.

If this is your first boat, or a type of boat you are not experienced in using, we recommend that you practice operating the boat in peace and quiet. Get to know the way the boat reacts to sea and to the controls under different speed, sea and loading conditions before you cast off for your first “real” maiden voyage.

Remember that the captain of every boat is required by law to know and to observe applicable rules for traffic and safety at sea. Get to know the rules which apply to you and your waters, by contacting the relevant authority or sea safety organisation.

It is a good idea to go on some kind of boat operation course. We recommend that you contact a regional boat or sea safety organisation to find a suitable course.

Accidents and near misses

Life saving statistics show that inadequate care of boats and engines, and deficiencies in safety equipment are frequent causes of accidents and near misses at sea.

Make sure that your boat and engine are maintained in accordance with the advice in each instruction book, and that the necessary safety equipment is on board, and is in working condition.

Daily checks

Make it a habit to give the engine and engine bay a visual check before driving (**before starting the engine**) and after operation (**when you have stopped the engine**). This helps you to quickly discover whether any leakage of fuel, coolant, oil or any other abnormal event has happened, or is about to happen.

Manoeuvring

Avoid sudden or surprising rudder movements and gear shifting. There is a risk that passengers could fall over, or overboard.

A rotating propeller can cause severe injury. Check that there is nobody in the water before you engage forward / astern (reverse) drive. Never drive close to bathers or in areas where you could reasonably expect that people could be in the water.

Fuel filling

There is always a risk of fire and explosion during fuel filling. Smoking is not permissible, and the engine should be stopped.

Never over-fill the tank.

Shut the tank cap securely. Only use the fuel recommended in the instruction book. The wrong grade of fuel can cause malfunctions or stop the engine. In a diesel engine, it can also cause the regulation rod to bind and the engine will over-rev, entailing a strong risk of personal injury and machinery damage.

Do not start the engine.


Do not start the engine if you suspect a fuel or LPG leak in the boat, close to explosive media, or if there is a spillage of explosive media. An explosive environment entails a risk of fire and/or explosion.

⚠ Carbon monoxide poisoning

When a boat moves forwards, an area of low pressure air forms behind the boat. In adverse conditions, this low pressure can be so strong that the boat's own exhaust fumes are sucked into the cockpit or cabin, which entails a risk of carbon monoxide poisoning for all aboard.

The problem of low-pressure suction is worst in high, wide boats with a square transom. But even in other types of boats, low-pressure suction can be a problem in some conditions, such as if you drive with the hood up. Other factors which increase the low-pressure effect are wind conditions, load distribution, pitching, trimming, open windows and ventilators etc.

Most modern boats are designed so that the problem of low-pressure suction is very rare, however. If low-pressure suction does occur anyway, do not open hatches or ventilators in the forward part of the boat. Strangely enough, this makes the problem worse. Try changing speed, trimming or load distribution instead. Also try taking down/opening the hood or modifying it in some other manner. Ask your boat dealer for advice about the best solution for your particular boat.



⚠ Remember

- Safety equipment: Life jackets for everybody aboard, communication equipment, emergency rockets, approved fire extinguisher, first aid kit, life buoy, anchor, paddle, torches etc.
- Spare parts and tools: Impeller, fuel filters, fuses, tape, hose clamps, engine oil, propeller and tools for the jobs you could be expected to have to do.
- Take your chart out and study your planned route. Calculate distance and fuel consumption. Listen to weather reports.
- Tell your friends/relatives about route plans if you undertake a long journey. Remember to notify changed plans or delays.
- Inform everybody aboard about where the safety equipment is located, and how it works. Make sure that there is more than one person aboard who can start and operate the boat safely.

This list can be extended, since the need for safety equipment varies with the type of boat, and where or how it is used etc. We recommend that you ask a regional boat or sea safety organisation for more detailed maritime safety information.

Safety advice for care and maintenance work

Preparations

Knowledge

The Instruction Book contains instructions for doing the most common service and maintenance tasks in a safe and correct manner. Read them carefully before starting work.

Literature for more major tasks is available from your Volvo Penta dealer.

Never do a job if you are not entirely sure about how to do it. Contact a Volvo Penta dealer for assistance instead.

Stop the engine.

Stop the engine before opening or removing the engine hatch/hood. Care and maintenance work should be done with the engine stopped unless otherwise specified.

Prevent the engine from being started by cutting the current with the battery isolator, or remove the cable from the battery positive pole before you start service work. Fix a notice by the helmsman's seat to say that work is in progress.

Working with, or going close to a running engine is a safety risk. Loose clothes, long hair, fingers or dropped tools can catch on rotating components and cause severe injury. Volvo Penta recommends that all service work which requires the engine to be running should be done by a Volvo Penta authorised workshop.

Lifting the engine

The existing lugs on the engine (or reverse gear) should be used for lifting. Always check that the lifting devices are in good condition and that they have the correct capacity for the lift (engine weight together with reverse gear and auxiliaries, if fitted). The engine should be lifted with an adjustable lifting boom for safe handling. All chains or cables should be parallel to each other and should be as square as possible to the top of the engine. Please note that auxiliary equipment installed on the engine could change its centre of gravity. Special lifting devices may then be needed to obtain the correct balance and safe handling. Never do any work on an engine which just hangs from a lifting device.

Before starting

Re-install all guards which have been removed during service work, before re-starting the engine. Make sure that there are no tools or other objects left behind on the engine.

Never start a turbocharged engine without the air filter in place. The rotating compressor turbine in the turbocharger can cause severe injury. There is also a risk that foreign bodies could be sucked in and cause machinery damage.

Fire and explosion

Fuel and lubrication oil

All fuel, most lubricants and many chemicals are flammable. Always read and observe the advice on the packages.

Work on the fuel system must be done with the engine cold. Fuel leakage and spills on hot surfaces or electrical components can cause fires.

Store oil and fuel soaked rags and other flammable material in a fire-proof manner. Oil soaked rags can self-ignite in certain circumstances.

Never smoke when filling fuel, lubrication oil or close to fuel filling stations or the engine bay.

Non-original spare parts

Components in fuel systems and electrical systems on Volvo Penta engines are designed and manufactured to minimise the risk of explosions and fire, in accordance with applicable legal requirements.

The use of non-original spare parts can cause a fire.

Batteries

Batteries contain and give off an explosive gas, especially when charged. This gas is very flammable and highly explosive.

Smoking, open flames or sparks must never occur in or near to batteries or the battery locker.

Incorrect connection of a battery cable or start cable can cause a spark which can be sufficient, in its turn, to make the battery explode.

Start spray

Never use start spray or similar products as a starting aid. Explosions could occur in the inlet manifold. Danger of personal injury.

Hot surfaces and fluids

A hot engine always offers the risk of burns. Be on your guard against hot surfaces, such as the exhaust manifold, turbocharger, sump, charge air pipe, starting heater, hot coolant and hot lubricating oil in pipes and hoses.

Carbon monoxide poisoning

Only start the engine in a well-ventilated area. When operated in a confined space, exhaust fumes and crankcase gases must be ventilated.

Chemicals

Most chemicals, such as glycol, rust preventer, conservation oils, degreasers etc. are hazardous. Always read and observe the advice on the packages.

Some chemicals, such as conservation oils, are flammable and also hazardous to breathe. Ensure good ventilation and use a protective mask for spraying. Always read and observe the advice on the packages.

Store chemicals and other hazardous material out of the reach of children. Hand in surplus or used chemicals to a recycling station for destruction.

Cooling system

There is always a risk of water entry when any work is done on the seawater system. For this reason, stop the engine and close the sea cocks before you start work.

Avoid opening the coolant filling cap when the engine is hot. Steam or hot coolant can spray out and cause scalding.

If the filler cap, coolant hose etc., still has to be opened or removed when the engine is hot, undo the filler cap slowly and carefully, to let the pressure out before removing the filler cap completely and starting work. Note that the coolant can still be hot and cause scalding.

Lubrication system

Hot oil can cause burns. Avoid skin contact with hot oil. Make sure that the oil system is de-pressurised before starting work. Never start or run the engine with the oil filler cap removed, because of the risk of oil spillage.

Fuel system

Always protect your hands when searching for leaks. Fluids which leak under pressure can force their way into body tissue and cause severe injury. Risk of blood poisoning (septicaemia).

Always cover the alternator if it is located beneath the fuel filters. Fuel spillage can damage the alternator.

Electrical system

Cut the current

Before any work is done on the electrical system, the engine must be stopped and the current cut by switching off the battery isolator. Shore current for engine heaters, battery chargers or other auxiliary equipment connected to the engine must be disconnected.

Batteries

Batteries contain a highly corrosive electrolyte. Protect your eyes, skin and clothes during charging and other handling of batteries. Always use protective goggles and gloves. If this comes into contact with your skin, wash at once with soap and a lot of water. If you get battery acid in your eyes, flush at once with

Introduction

This instruction book has been prepared to give you the greatest possible benefit from your Volvo Penta marine engine. It contains the information you need to be able to operate and maintain the engine safely and correctly. Please read the instruction book carefully and learn to handle the engine, controls and other equipment in a safe manner before you cast off on your maiden voyage.

Always have the instruction book available. Store it safely and do not forget to hand it over to the next owner if you sell your boat.

Environmental care

All of us want to live in a clean, healthy environment. Where we can breathe clean air, see healthy trees, have clean water in lakes and seas, and be able to enjoy the sunlight without fearing for our health. Unfortunately, this is not self-evident these days, it is something all of us must work hard for.

As a manufacturer of marine engines, Volvo Penta has particular responsibility and for this reason, environmental care is a core value in our product development. Volvo Penta has a wide engine programme these days, where considerable progress has been made in reducing exhaust fumes, fuel consumption, engine noise etc.

We hope that you will be want to preserve these values. Always observe the advice in the instruction book about fuel grades, operation and maintenance, to avoid unnecessary environmental impact. Please contact your Volvo Penta dealer if you notice any changes such as increased fuel consumption or increased exhaust smoke.

Moderate your speed and distance so that wake and noise do not disturb or damage animal life, moored boats, jetties etc. Leave the archipelago and harbours in the same state you would like to find them. Remember to always hand in drained oil, coolant, paint and wash residue, used batteries etc. for destruction at a recycling station.

If we all pull together, we can make a valuable contribution to the environment together.

Running in

The engine must be "run in" during its first 10 hours, as follows:

Use the engine in normal operation. Full load should only be applied for short periods. Never run the engine for a long period of time at constant speed during this period.

Higher oil consumption is normal during the running in period. For this reason, check the oil level more frequently than normally recommended.

After the first period of operation, the specified warranty inspection "First service inspection" can be done. For more information: Please refer to the Warranty and Service book.

Fuel and oils

Only use the fuels and oils recommended in the instruction book. Other grades can cause malfunctions, increased fuel consumption and eventually even shorten the life of the engine.

Always change the oil, oil filter and fuel filter at the specified intervals.

Service and spare parts

Volvo Penta marine engines are designed for high reliability and long life. They are built to withstand a marine environment, but also to have the smallest possible environmental impact. Through regular service and use of Volvo Penta original spare parts, these qualities are retained.

Volvo Penta's world-wide network of authorised dealers is at your service. They are Volvo Penta product specialists, and have the accessories, original spares, test equipment and special tools needed for high quality service and repair work.

Always observe the maintenance intervals in the instruction book, and remember to note the engine/transmission identification number when you order service and spare parts.

Certified engines

If you own or operate an emission certified engine it is important to be aware of the following:

Certification means that an engine type has been checked and approved by the relevant authority. The engine manufacturer guarantees that all engines made of the same type are equivalent to the certified engine.

This makes special demands on the care and maintenance you give your engine, as follows:

- Maintenance and service intervals recommended by Volvo Penta must be complied with.
- Only Volvo Penta original spares may be used.
- Service on injection pumps, pump settings and injectors must always be done by an authorised Volvo Penta workshop.

- The engine must not be converted or modified, except for the accessories and service kits which Volvo Penta has approved for the engine.
- Installation changes to the exhaust pipe and engine air inlet ducts must not be done.
- No seals may be broken by unauthorised personnel.

The general advice in the instruction book about operation, care and maintenance apply.

⚠ IMPORTANT! Late or inadequate maintenance/ service or the use of spare parts not approved by Volvo Penta will invalidate AB Volvo Penta's responsibility for the engine specification being in accordance with the certificated variant.

Volvo Penta accepts no responsibility or liability for any damage or costs arising due to the above.



Warranty

Your new Volvo Penta marine engine is covered by a limited warranty, under the conditions and instructions compiled in the Warranty and Service book.

Please note that AB Volvo Penta's liability is limited to the specification in the Warranty and Service book. Read it carefully, as soon as possible after delivery. It includes important information about warranty cards, service, maintenance, which it is the responsibility of the owner to know, check and carry out. If this is not done, AB Volvo Penta may fully or partly refuse to honour its warranty undertakings.

Please contact your Volvo Penta dealer if you have not received a Warranty and Service book, or a customer copy of the warranty card.

Identification numbers

There are type plates on the engine and transmission, marked with identification numbers. This information must always be used as a reference when service and spare parts are ordered. You will probably find similar plates on your boat and its equipment. Note this information below, make a copy of the page and store it in a safe place, so that you can have the information available if the boat is stolen.

The appearance and location of the type plates is shown below. The figures in brackets refer to the location of the identification number on the type plate.

Engine

Product designation (1) **D12D-C MH**

Serial and base engine number (2)

Product number (3).....

Control unit

“Dataset” (parameter file) (4)

Main software (5).....


Certification, IMO

Reverse gear

Product designation (6)

Serial number (7).....

Product number (8).....



Presentation

The D12D-C MH is an in-line, direct injection 6-cylinder marine diesel engine.

The engine has electronically controlled fuel injection, a turbocharger, aftercooler, heat exchanger and thermostatically controlled freshwater cooling, electronically controlled engine speed control and shifting.

The exhaust manifold and turbocharger are freshwater cooled to reduce heat radiation to the engine room

Technical description

Engine and cylinder block

- The cylinder block and cylinder head are manufactured of alloyed cast iron
- Induction hardened crankshaft journalled in seven main bearings
- Replaceable wet cylinder liners
- Gallery oil cooled cast aluminium pistons
- Three piston rings, including a “keystone” type top ring
- Induction hardened overhead camshaft with roller rocker arms
- Four valves per cylinder
- Replaceable valve seats and valve guides

Fuel system

- Microprocessor based fuel supply control unit
- Gear driven fuel feed pump
- Centrally located unit injectors with electromagnetically controlled fuel valves
- Spin-on fine fuel filter with water trap

Lubrication system

- Freshwater cooled oil cooler
- Gear driven oil pump
- Side mounted or rear mounted full flow and bypass oil filters of spin-on type

Turbocharging system


- Turbocharger with freshwater cooled turbine housing

Cooling system

- Tube heat exchanger (or 1- circuit keel cooling) with expansion tank
- Plate type freshwater cooled aftercooler
- Gear driven seawater pump


Electrical system

- 24V electrical system, alternator (60A) with charge sensor
- Engine mounted emergency stop button
- Power modul



D12D-C MH

1. Alternator
2. Expansion tank
3. Level glass, coolant
4. Coolant filler cap
5. Charge air cooler (located beneath cover)
6. Air filter
7. Oil cooler, reverse gear
8. Crankcase breather filters
9. Heat exchanger
10. Control unit (located behind heat exchanger)
11. Seawater pump



D12D-C MH


1. Exhaust pipe, dry
2. Turbocharger
3. Fine fuel filter with water trap
4. Emergency stop button
5. Oil filler cap
6. Coolant pump
7. Oil sump
8. Oil cooler, engine (loc. in engine block)
9. Lubrication oil filter
10. By-pass filter for lubrication oil
11. Coolant filter
12. Oil dipstick, engine
13. Oil filler cap
14. Oil drain pump (optional)
15. Starter motor
16. Reverse gear Twin Disk MG5114 DC

Instruments


This chapter describes the instrument and control panels sold by Volvo Penta for your engine.

If you want to supplement the instrumentation, or if your boat is equipped with instruments not described here, or you are not sure about their function, please contact your Volvo Penta dealer.

Instruments



1. EVC system tachometer (with display)
2. Voltmeter
3. Oil pressure gauge
4. Temperature gauge



Ignition lock

A tab with the key code accompanies the ignition keys, and is used to order extra ignition keys. Do **not** store the code where it is accessible to unauthorized persons.

S = Stop position.


0 = Key can be inserted and removed.

I = System voltage on (drive position).

II = Not used.

III = Start position.

⚠ IMPORTANT! Read the starting instructions in the “Starting the engine” chapter.



Start/stop panel

The start/stop panel is used to start or stop the engine. The starter key in the main control panel must be in position “I” (driving position) for the engine to start. The engine can only be stopped if the control panel is activated.

⚠ IMPORTANT! Read the starting instructions in the “Starting the engine” chapter.

Alarm display (optional extra)

The following warning lamps should never light up during operation. On the other hand, the warning lamps light up when the starter key is first turned to the drive position. Check that all lamps function. When the engine has started, all lamps should have gone out. The lamps flash if the diagnostic function has registered malfunction. When the fault has been acknowledged, the lamp gives continuous light.

NOTE! Warning lamps should never light up during operation



Oil pressure (red indication)

If the oil pressure lamp lights up during operation, the oil pressure in the engine is too low. Stop the engine at once.

- Check the oil level in the engine. Please refer to “Maintenance: Lubrication” to check and top the oil up.
- Also check that the oil filters are not blocked. Please refer to “Maintenance: Lubrication system”

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

⚠ WARNING! Continued operation when the oil pressure is too low can cause serious engine damage.

Water in fuel filter (orange indication)

If the lamp lights up, there is too much water in the water trap in the fuel filters.

- Empty the water trap underneath the secondary fuel filter. Please refer to “Maintenance: Fuel system”.

Please refer to the “In case of emergency” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.



Battery (orange indication)



The battery lamp lights up if the alternator is not charging. Stop the engine if this lamp lights up during operation. If the lamp lights up, this can be due to a fault in the electrical system or because the alternator drive belt is slack.

- Check the alternator drive belts. Please refer to “Maintenance: Engine, general”.
- Also check that there is no poor contact/broken wires.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

⚠ WARNING! Do not continue operation if there is any problem with the alternator drive belts. This could cause serious engine damage.

Coolant temperature (red indication)




The coolant temperature lamp lights up when the coolant temperature is too high. Stop the engine if this lamp lights up during operation.

- Check the coolant level. Please refer to “Maintenance: Fresh water system”.
- Check that the sea water filter is not blocked. Please refer to “Maintenance: Sea water system”.
- Also check the impeller in the sea water pump. Please refer to “Maintenance: Sea water system”.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

⚠ WARNING! Do not open the coolant filler cap when the engine is warm, except in emergencies. Steam or hot fluid could spray out.



Coolant level (orange indication) 

The coolant lamp lights up when the coolant level is too low.

- Check coolant level. Please refer to “Maintenance: Lubrication system”.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

Oil level (orange indication) 

The oil level lamp lights up when the oil level is too low.

- Check the oil level. Please refer to “Maintenance: Fresh water system”.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

Serious fault (red indication) 

The lamp lights up when a serious fault occurs.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.



Fault (orange indication) 

The lamp lights up when a fault occurs.

Please refer to the “If something happens” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

EVC control panel

The control panel is used in combination with the EVC system tachometer. The tachometer display shows operating information and menus that can be navigated from the control panel.



Activation button

Used to activate and lock the control panel and helm-station.


Indication (red):

Off: Control panel not activated.

Lit: Control panel activated.

Flashes: Control panel not activated due to the control lever not being in neutral or the system has been locked from another control panel.

Padlock

The padlock symbol lights if the control panel is locked manually by depressing the -button, or if exchange has been activated by routine "Change of control panel during journey".

Lit: The system is locked and the engine can only be controlled from the activated control panel.

Neutral button

Used to disengage the drive so that the engine speed can be increased without driving (warming up).

Indication (green):

Off: Drive engaged.

Lit: Control lever in neutral position.

Flashes: Drive disengaged or system in calibration mode.

Navigation wheel

Used to navigate through the menus shown on the tachometer EVC system display. Navigate through the menus by turning the wheel. Depress the wheel to confirm a selection.

Tachometer display selection (twin installation, port or starboard tachometer)

Is used to select which of the engines menu systems should be navigable from the control panel. The menu is shown on the display of the corresponding engines tachometer. Select port or starboard.

Indication (red/green):

Off: Not possible to navigate in menu.

Lit: Possible to navigate in menu for selected engine, port (red), starboard (green).

Multifunction button


Used to increase or decrease the instrument's and panel's backlighting.


Depress the button for at least 1 second to turn the backlighting on or off. The backlighting can be adjusted in five stages by pressing the multifunction button.

If the button is pressed on an inactive control panel, operating information is shown on the display(s) and it is possible to navigate in the menus.


Back button

Used to back a step in the menu.

 **IMPORTANT!** Always press the buttons firmly, and for at least one second each time.



Main menu structure



EVC System Tachometer

Introduction

Volvo Penta EVC System Tachometer presents relevant boat and engine information to the helmsman. Information is presented on a display in the tachometer.

Information is depending on engine model, number of sensors and type of accessories.

Using the instrument

Start-up screen

This is the start-up screen for the EVC System Tachometer. After a few seconds the first item in MAIN MENU will appear.

Main menu

Navigating the menus

Navigate the menus by turning NAVIGATION WHEEL clockwise or counter-clockwise. Views with a POINTING HAND-symbol indicates a SUB-MENU. To enter a SUB-MENU, push NAVIGATION WHEEL.

Speed (Optional)

Boat speed. Requires multisensor or GPS.

Water temp (Optional)

Water temperature. Requires multisensor.

Depth (Optional)

Water depth. Requires multisensor.

Trip menu (Optional)

Shows trip information. Requires the following:

- Multisensor or NMEA 0183/NMEA 2000 compatible component (plotter, GPS, paddle wheel etc)
- Fuel level sender
- Trip computer software

Gauges menu

Shows data parameters.

Settings menu

The SETTINGS MENU allows the user to set various options for the EVC System and to calibrate various parameters.

Faults list

Number after word FAULTS indicates number of faults stored in FAULTS LIST. List is reset when system is rebooted.

NOTE! Faults list is not shown if no faults are registered.

Trip menu (extra optional)

In the TRIP MENU the user gets trip information from the EVC System and the user is allowed to select which view that should be presented in the EVC System Tachometers MAIN MENU as trip information. To get trip information following are required:

- Multisensor or NMEA 0183/NMEA 2000 compatible component (plotter, GPS, paddle wheel etc)
- Fuel level sender
- Trip computer software


NOTE! The accuracy of trip information concerning, and based on, remaining fuel volume depends on which method the user has chosen for calibrating the fuel tank.

When in TRIP MENU, select view by turning NAVIGATION WHEEL. To select view as favorite, push NAVIGATION WHEEL. System returns to MAIN MENU.

Push BACK BUTTON to return to MAIN MENU without setting a new favorite.

Units are user selectable. See section "Units".

Trip menu structure




Gauges menu

In GAUGES MENU the user gets information from analogue senders, placed on the engine. If the data is not available the parameter will not be displayed.

When in GAUGES MENU, select view by turning NAVIGATION WHEEL. To select view as favorite, push NAVIGATION WHEEL. System returns to MAIN MENU.

Push BACK BUTTON to return to MAIN MENU without setting a new favorite.

Gauges menu structure



Settings menu

In the SETTINGS MENU the user is allowed to set various options for the EVC system and to calibrate various parameters.


⚠ IMPORTANT! For all settings and calibration procedures: Activate helm station by pushing the ACTIVATION BUTTON.

NOTE! For twin installations always perform the settings on the port side system. Port side is the master side.

When in SETTINGS MENU, select view by turning NAVIGATION WHEEL. Views with a POINTING HAND-symbol indicates a SUB-MENU. To enter a SUB-MENU, push NAVIGATION WHEEL.


Push BACK BUTTON to return to MAIN MENU.

Settings menu structure



Depth alarm (extra optional)

All depth alarm functions are accessed through this menu. A multisensor needs to be installed.



DEPTH ALARM, ON/OFF

Depth alarm can be switched ON/OFF.

SET DEPTH

Adjust the depth alarm value by turning the NAVIGATION WHEEL. The value can be adjusted at a resolution of 0.1 m or 1 ft.



Once adjustment value is reached, the data is stored by pushing NAVIGATION WHEEL.

DEPTH OFFSET

The depth sounder can be placed somewhere on the hull that gives another depth than the desired depth. You can then add or subtract a distance so that the display shows the depth from, for example, the lowest point on the boat, or from the surface.

Adjust the depth offset value by turning the NAVIGATION WHEEL. The value can be adjusted at a resolution of 0.1 m or 1 ft.

Once adjustment value is reached, the data is stored by pushing NAVIGATION WHEEL.



Depth alarm pop-up

The depth alarm pop-up will appear when the depth is less than the depth alarm setpoint. The pop-up shows the actual depth.

Acknowledge depth alarm by pushing NAVIGATION WHEEL.

The depth alarm pop-up will re-appear every 30 seconds until the depth increases and exceeds the depth alarm setpoint.

Depth alarm signal loss

If the depth alarm is enabled and the depth signal is lost, for instance in the case of sensor malfunction, the depth alarm signal loss pop-up will appear.

Select units and language

Choose which units and languages to display.


NOTE! Language and unit settings must be performed in all EVC system tachometers.

US or METRIC

1. Activate helm station by pushing the ACTIVATION BUTTON.
2. Select SETTINGS from MAIN MENU by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter SETTINGS MENU.
3. Select UNITS and push NAVIGATION WHEEL.
4. Select US OR METRIC and push NAVIGATION WHEEL.
5. Set US or METRIC units by turning NAVIGATION WHEEL and confirm by pushing NAVIGATION WHEEL.

DISTANCE

1. Activate helm station by pushing the ACTIVATION BUTTON.
2. Select SETTINGS from MAIN MENU by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter SETTINGS MENU.
3. Select UNITS and push NAVIGATION WHEEL.
4. Select DISTANCE and push NAVIGATION WHEEL.
5. Set distance unit: km, nm or miles and confirm by pushing NAVIGATION WHEEL.



LANGUAGE

1. Activate helm station by pushing the ACTIVATION BUTTON.
2. Select SETTINGS from MAIN MENU by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter SETTINGS MENU.
3. Select SEL LANGUAGE and push NAVIGATION WHEEL.
4. Select language and confirm by pushing NAVIGATION WHEEL.



Fuel tank calibration

There are two possible calibration methods for the fuel tank. One approximative, FULL TANK CALIBRATION, and one more precise, FUEL MULTIPOINT CALIBRATION. A fuel level sender need to be installed.

NOTE! If FUEL TANK CALIBRATION is not shown in SETTINGS MENU, please contact your Volvo Penta dealer.

FUEL MULTIPOINT CALIBRATION

When FUEL MULTIPOINT CALIBRATION is selected, the fuel level sender is calibrated in five equally divided steps; 20% full (pos 1), 40% full (pos 2), 60% full (pos 3), 80% full (pos 4) and 100% full (pos 5)

NOTE! To perform multipoint calibration, fuel tank must be LESS than 20% full. If calibration skips POS 1 and goes directly to POS 2, the fuel tank contains too much fuel and the calibration will not be correct.

1. Activate helm station by pushing the ACTIVATION BUTTON.
2. Select SETTINGS from MAIN MENU by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter SETTINGS MENU.
3. Select FUEL TANK CALIBRATION and push NAVIGATION WHEEL.
4. Select FUEL MULTIPOINT CALIBRATION by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter FUEL MULTIPOINT CALIBRATION.




NOTE! The fuel multipoint calibration procedure differs depending on EVC software release.

5A. If the number after “POS” in the display is flashing:

Fill fuel tank with displayed volume (POS 1) and push NAVIGATION WHEEL. Add fuel (do not reset the pump) up to displayed volume for each POS until the tank is filled.


Push BACK BUTTON to return to SETTINGS MENU.



5B. If the number after “POS” is **not** flashing:

Fill fuel tank with displayed volume (POS 1) and push NAVIGATION WHEEL. Repeat procedure for each POS until the tank is filled.

Push BACK BUTTON to return to SETTINGS MENU.



FUEL FULL TANK CALIBRATION

When FUEL FULL TANK CALIBRATION is selected, the fuel level sender is calibrated in one step. This only gives an approximated value of the fuel level. Therefore all trip data concerning and based on, remaining fuel volume should be recognized as approximated values only.

1. Activate helm station by pushing the ACTIVATION BUTTON.
 2. Select SETTINGS from MAIN MENU by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter SETTINGS MENU.
 3. Select FUEL TANK CALIBRATION and push NAVIGATION WHEEL.
 4. Select FUEL FULL TANK CALIBRATION by turning NAVIGATION WHEEL. Push NAVIGATION WHEEL to enter FULL TANK CALIBRATION.
 4. Fill fuel tank and push NAVIGATION WHEEL.
- Push BACK BUTTON to return to SETTINGS MENU.



Approximated trip data

This pop-up will be shown every time after start-up if FUEL FULL TANK CALIBRATION is performed.




Fuel alarm pop-up

The fuel level alarm pop-up will appear when the fuel level is lower than fuel alarm setpoint. The pop-up shows the percentage of fuel remaining.

Acknowledge fuel alarm by pushing NAVIGATION WHEEL.

Fuel level alarm pop-up will re-appear every 10 minutes until the fuel level in tank is higher than fuel alarm setpoint.



Fuel level signal loss

If the fuel level has been set and the fuel level signal is lost, for instance in the case of sensor malfunction, the fuel level alarm signal loss pop-up will appear.

Speed factor

The speed factor for the boat's paddle wheel speed sensor can be adjusted at a resolution of 1% and is used by the EVC to apply a correction to the output from the speed sensor.

Set speed factor

Set speed factor while driving the boat. Compare displayed speed with speed data from GPS (or other boat) and adjust the speed factor until they correspond.

Adjust the speed factor by turning the NAVIGATION WHEEL.

Once adjustment value is reached, the data is stored by pushing NAVIGATION WHEEL.



Information message

Start attempt with gear engaged

The engine control lever must always be in neutral before starting. If not, this pop-up will be shown.

Approximated trip data

This pop-up will be shown every time after start-up if FUEL FULL TANK CALIBRATION is performed.

Retrieving faults

The EVC system is retrieving faults from its nodes.

Monitoring mode (inactive station)

An inactive station can show system information. Push MULTIFUNCTION BUTTON on the inactive station.

It is possible to navigate the menus when in monitoring mode.

EVC System Display (extra optional)


Introduction

Volvo Penta EVC system display is an instrument which displays operating information about the engine and allows you to communicate with the engine's electrical system.


Operation information is shown on an LCD display. The driver can select the display mode operative on the display with the aid of the five buttons on the front of the instrument.

The four buttons at the furthest left are used to display operating information in different ways. The button at the furthest right is used to adjust the display contrast and to access the so-called configuration menu. Various settings etc. can be done in it. You can also use the configuration menu to reach the display mode SYSTEM INFORMATION (which can also be reached via button 2, please refer to the schedule below). This display mode functions in the same way as the display in the tachometer (EVC System Tachometer).

Before the display is used, it may be necessary to modify the way that the display shows operating information, to comply with user requirements. You can see the settings that can be changed in the section about the configuration menu.



Structure of the display functions





Start image

This is the starting image that is shown on the display for a brief period after starting.

If the unit gives a constant audible warning after starting, the self-test has failed. The unit will still work, but may behave in an unexpected manner.

Symbols for operating information

- Engine speed
- Coolant temperature
- Engine temperature
- Fuel pump pressure
- Oil pressure
- Coolant temperature
- Speed
- Fuel consumption/time
- Turbocharge pressure (current)
- Induction air temperature
- Exhaust temperature
- Voltage
- Oil pressure, reverse gear
- Oil temperature, reverse gear
- Fuel level
- Differential pressure, oil filter




Figure for single engine installation





Figure for twin engine installation


Display after starting screen

Display mode ENGINE (button 1) is always shown after the starting screen when the display is first started up (more information about this display mode can be found below in the instructions). Once the display has been used, it will always show the display mode when it starts up, that was selected when the display was last switched off.




Connection fault

If the display does not register transfer of operating information from the electrical system, the pop-up window will flash CONNECTION LOST. When operating information has been registered/reset, the pop-up window disappears.



Set display contrast

Press button 5 (furthest right) to set display contrast. Then press the appropriate buttons to adapt the levels, then save the settings by pressing EXIT. The display unit has 5 contrast settings.



Configuration menu (button 5)

(depressed for longer than 3 s)


The configuration menu is used to:


- access the display mode SYSTEM INFORMATION.
- do various settings for the display.
- reach information and functions for servicing the display.

Please refer to the configuration menu structure below and read the following section, which explains each section in the menu.


Note! The port engine or both engines must have the ignition switched on when display settings are changed.

Configuration menu structure






SYSTEM INFORMATION display mode for single engine installations




SYSTEM INFORMATION display mode for twin engine installations



Control panel



Alarm example



Display mode System Information

SYSTEM INFORMATION is a display mode that functions in the same way as the display in the tachometer (EVC System Tachometer). You navigate round these functions, using the buttons on the free-standing control panel.

In display mode SYSTEM INFORMATION there are several functions:

- Display of operating information, information messages and alarm (note! The display is adapted to suit the size of the panel in the tachometer).
- Settings for displaying operating information in this display mode.
- All calibrations.

Detailed instructions for the functions in display mode SYSTEM INFORMATION are found in the section about the tachometer in this owner's manual .

Information message and alarm



The display automatically switches to display mode SYSTEM INFORMATION when the electrical system needs to show information messages or alarms. Instructions about how information messages and alarms should be handled are found in the section about the tachometer and in the section "In case of emergency" in this owner's manual.

Settings

Menu SETTINGS is used to do various settings for the display.

- **Language:** This is where you select the language that the display should use (8 different languages are available).
- **Bleep:** This is where you select whether a beep should be heard when any button is depressed. ON/OFF.
- **Engine:** This is where you select the engine for which operating data will be displayed. SINGLE, PORT, STARBOARD or TWIN.
- **Engine series:** This is where you select the engine for which the display has been installed D1/D2, >D2. The display is pre-set for use with engines larger than D2.

- **Display:** This is where you set the measurement intervals of the speedometers and tachometers.
Rpm engine: [2500 rpm: 9000 r/min] in stages of 500 rpm
 - Speed: Change speed display (on/off)
 - Speed: [10 KNOT: 100 KNOT] in states of 10 (in the appropriate speed intervals)
 - Graph interval: 2 MIN, 10 MIN, 30 MIN, 60 MIN, 2 H, 4 H, 8 H
- **Units:** (This menu is only displayed if LOCAL has been selected in menu SETTINGS). This is where you select the measurement units to be used to display operating information. (GLOBAL is pre-set, which means that the units of measurement are pre-set, but they can be changed if LOCAL is selected in menu UNITS).
 - Speed: KNOT, MPH, KM/H
 - The distance is adjusted to suit the speed unit: NM, MILE, KM
 - Oil or Turbo pressure: kPa, PSI
 - Volume: LITER, GAL, Imperial GAL
 - Fuel consumption / time: is adjusted to suit the volume unit: L/H, GAL/H, IGAL/H
 - Temperature: °C (CELSIUS), °F (Fahrenheit)



System

Menu SYSTEM is intended to provide the necessary functions and information for service technicians.

- **Demo:** Switches between demo mode ON/OFF
The unit is in normal operation mode when Demo is OFF.
- **Com Viewer:** Shows the latest messages received on the communication inputs
- **Prog tx:** Transfers the contents of the application program in the flash memory to other CANtrak units on the same CANbus link
- **About :** Shows the following information:
 - ID no:** Display serial number
 - Eeprom:** No. of writes to the EEPROM
 - Vers:** Software version number
 - Chk:** Flash memory checksum
 - Part no:** Volvo's part number for the software
 - Source:** Shows the source of the received data
 - Label:** Label allocated on the bus. Each unit on the same bus must have its own unique label




Figure for single engine installation




Figure for twin engine installation

Display mode Engine (Button 1)

This display mode shows the engine speed and boat speed in the form of standard instruments, together with a trip computer and fuel level gauge. The fuel level gauge are displayed if there is a tank sender installed.

Note! Trip information is only displayed if following are installed:

- Multisensor or NMEA 0183/NMEA 2000 compatible component (plotter, GPS, paddle wheel etc)
- Fuel level sender
- Software for trip computer (order and download from VODIA website)

The trip computer shows various types of information if you repeatedly press the button ENGINE (ENGINE) (button 1). Please refer to the trip computer menu below.


Note! Only metric values are displayed, but other units can be displayed if they have been chosen in the configuration menu.


The scale values for maximum engine speed and maximum speed can be set in the configuration menu.

If information about boat speed is not available, the display shows coolant temperature instead.



Menu, trip computer

Button 1
Changes display each time the button is pressed





Example of display in several windows for single engine installation



Example of display in several windows for twin engine installation




Figure for single engine installation

Press button 5 to choose setting mode




Figure for twin engine installation




Figure for single engine installation

Buttons 1 to 4 are used to adjust the corresponding window (please refer to the black markings)




Figure for twin engine installation

Display mode Multi (button 2)

This display mode shows operating information in four different windows (see below). The user can choose the operating information to be displayed in each window.

The information can be displayed as figures or as standard instruments. Display indication shifts between the two modes when you press button 2 repeatedly.

If an item of operating information is not available, the unit displays "—" and the analogue gauge needle is not shown.

From this display mode MULTI, you can also reach display mode that functions in the same way as the smaller display in the tachometer. Read more about this display mode SYSTEM INFORMATION in the configuration menu section.

Set the appearance of the display mode Multi

Display mode MULTI has a mode to set the operating information to be displayed in each window.

The setting mode is reached by pressing button 5 (furthest right), when you are in the display mode MULTI. Please refer to the illustrations below.

Note! The type of operating information available depends on the electrical system in the boat and the sensors that the boat is equipped with. Optional sensors include depth gauge, water temperature, speed, trim angle and rudder angle.

Note! This applies to the graphic display: The maximum engine speed range can be set on the configuration menu.

The voltage interval can be [8V: 16V] or [16V: 32V] and is changed automatically, depending on the latest data value.




Figure for single engine installation




Figure for twin engine installation

Display mode Trip (button 3)

This display mode shows:


- Fuel used after last zeroing
- Instantaneous fuel consumption (amount of fuel used per hour) (If speed information is available, instantaneous fuel consumption can also be calculated in relation to distance.)
- Operation time after last zeroing
- Total operating time (can not be zeroed)

If you want to zero the trip values (trip fuel consumption and trip operating time), keep button 3 depressed for 1 second. The unit beeps and the values are zeroed.


Note!

When the display is set for a twin engine installation, the information displayed for each engine will be the sum of the values from both engines, apart from operating time. Operation times for twin engines are shown separately.

The size of the operating hours figures shown on the display is reduced if the number does not fit in the window.



Window with curve for single engine installation (shows engine speed)



Window with curve for twin engine installation (shows engine speed)

Display mode Graph (button 4)

In this display mode, operating information is displayed in the form of a histogram. Press button 4 repeatedly to show different operating information.

If an item of operating information is not available, that window can not be chosen.

If contact with the relevant information is lost during display, the curve will no longer be drawn, but the line will continue to scroll across the window.

Data for the port engine or single engine information is drawn with a black line.


Data for the starboard engine information is drawn with a gray line.

The maximum time interval can be set to one of the following values in the configuration menu: 2 min, 10 min, 30 min, 1 h, 2 h, 4 h, 8 h.

The interval on the Y axis is automatically adjusted for best indication.

Controls

This chapter describes the instrument panels sold by Volvo Penta for your engine. If your boat is equipped with controls which are not described here and you feel uncertain about the function, please contact the dealer you purchased the boat from.



Single lever control. Electronic

Operation

Both the shift function and engine speed control are controlled using the single lever control.


N = Neutral position (reverse/stern drive is disengaged and the engine runs at idle speed).

F = Reversing gear/stern drive engaged for movement ahead.

R = Reversing gear/stern drive engaged for movement astern.

T = Adjustment of engine speed.

NOTE! The engine can only be started if the Control lever is in the neutral position.



Disengaging the shift function


The shift function can be disengaged so that the control lever only affects the engine speed.

1. Move the lever to the neutral position (N)
2. Press the neutral button (N) in and hold it down while moving the control lever forward to the shift position (F).
3. Release the neutral button. The green indicator begins to flash to acknowledge that the shift function is disengaged.

The lever now only controls engine speed.

When the lever is moved back to the neutral position it will automatically re-engage. This is confirmed by the green indication which gives constant light.

⚠ WARNING! Take care not to engage the reversing gear/stern drive unintentionally.



Friction brake

The control is also equipped with a friction brake which can be adjusted for easier or stiffer lever movement as necessary.

Friction brake adjustment:

1. Stop the engine.
2. Move the control lever forwards to make the groove in the control lever hub accessible.
3. Put a screwdriver in the groove and disassemble the plug.
4. Adjust the friction brake (spanner size 8 mm):
Clockwise = stiffer lever movement
Anti-clockwise = easier lever movement
5. Install the plug.

Two lever control. Mechanical

Operation

The two lever control has separate levers for shifting (1) and speed control (2).

The control has a neutral position switch that only allows the engine to be started with the reversing gear in neutral.

Black lever (1):




N = Neutral position. Reversing gear is disengaged.

F = Reversing gear engaged for movement ahead.

R = Reversing gear engaged for movement astern.

Red lever (2):

Engine speed control.



Friction brake

The control has an adjustable friction brake for speed control.

Adjust the friction brake by turning the screw (control A) or lever (control B).


Turn clockwise (+) for **heavier** lever movement or anti-clockwise (-) for **lighter** lever movement.

Starting the engine

Make it a habit to give the engine and engine bay a visual check before starting. This will help you to discover quickly if anything abnormal has happened, or is about to happen. Also check that instruments and warning displays show normal values after you have started the engine.

To minimize starting smoke in cold starting, we recommend that a heater should be installed to warm the engine bay at temperatures below +5°C.

⚠ WARNING! Never use start spray or similar products as a starting aid. Explosion risk!



Before starting

- Open the fuel tap
- Open the sea cock (reverse gear)
- Do the tasks under the “Daily before first start” heading in the maintenance schedule.
- Turn the main switches on.
 - ⚠ **IMPORTANT!** Never disconnect the current with the main switches when the engine is running. This can damage the alternator.
- Start the engine bay fan, if one is installed, and let it run for at least four minutes.
- Check that the amount of fuel aboard is enough for your planned voyage.

General information about starting

The engine control lever must always be in neutral before starting. The engine management system ensures that the engine receives the correct amount of fuel - even when the engine is cold.

The idling speed is also governed by engine temperature, and is somewhat raised after a cold start.




Starting method

Put the reversing gear in neutral


Put the reversing gear in neutral by moving the control lever(s) to neutral at all control positions.

Two lever control: Also check that the engine speed lever is in the idling position.



Turn the ignition on


Turn the starter key to position I to switch the ignition on.



Check the warning lamps and LEDs

Each time the ignition is turned on, all bulbs and LEDs are illuminated on the main control panel. Check that all bulbs and LEDs function.

If the boat has more than one control panel, the lamps on the other panel(s) are not checked until the control panel(s) is(are) activated.




Activate the control position and lock the system.

Press the activation button for at least one second. When the button is released, the indication lights up to confirm that the control position is activated.

NOTE! If the indicator flashes, the control position has not been activated because the control lever(s) are not in the neutral position or the system has been locked from another control panel.

If the boat has more than one control panel, the system can be locked, so that the engine can only be controlled from the activated control board. Press the activation button for a further second to lock the system. The padlock sign lights up in confirmation.

Unlock the system by pressing the activation button for one second. This can only be done from an activated control panel.




Start the engine

Start using the ignition switch

Turn the key to position III. Release the key and let it key spring back to position I as soon as the engine has started.

NOTE! If repeated start attempts are needed, the key must be turned back to position 0 first.



Starting with the starter button

Press the starter button. Release the button as soon as the engine has started. Please note that if you start from an alternative control station, the starter key at the main control station must be in position I.

Overheating protection


If the starter motor is engaged for its maximum activation time (30 seconds), the starter motor circuit is cut automatically to protect the starter motor from overheating. Leave the starter motor to cool for at least five minutes (if possible) before making a new start attempt.

Read the instruments and warm the engine up

Allow the engine to idle for the first ten seconds, and check that instruments and warning displays show normal values. Check that no alarms are displayed and that no warning lamps are flashing.

Then warm the engine up at low speed and low load, so that reaches normal operating temperature before full power is used.

⚠ IMPORTANT! Never race the engine when it is cold.






Check the oil level in the reverse gear

Check the oil level when the reversing gear has reached operating temperature (please refer to the description in the "Maintenance" chapter under the "Reversing Gear" heading)

Operation

Learn to handle the engine, controls and other equipment in a safe and correct manner before you cast off on your maiden voyage. Remember to avoid sudden or surprising rudder movements and gear shifting. There is a risk that passengers could fall over, or overboard.

! WARNING! A rotating propeller can cause severe injury. Check that there is nobody in the water before you engage forward / aft drive. Never drive close to bathers or in areas where you could reasonably expect that people could be in the water.



Reading the instruments

Read all instruments and alarm displays directly after starting, and then regularly during your voyage.

Oil pressure

The oil pressure gauge should normally indicate between 4-5.5 bar. It will indicate a somewhat lower value when idling.

If the oil pressure is too low, the audible warning will sound automatically at the same time as the lamp in the warning display will flash.

Coolant temperature


The temperature gauge should normally indicate between 75– 95°C (167-203°F) in normal operation.

If the coolant temperature is too low, the audible warning will sound automatically at the same time as the lamp in the warning display will flash.

Charging

During operation, system voltage should be about 28 V for 24 Volt system voltage.

If there is a charge failure, the audible warning will sound automatically at the same time as the lamp in the warning display will flash.



Alarm

If a fault occurs, the audible warning will sound and the relevant warning lamp on the alarm panel will start to flash and the display will show a alarm pop-up.

1. Reduce engine speed to idling.
2. Acknowledged the larm by pressing the navigation wheel on the control panel once.

When the fault has been acknowledged, the lamp concerned gives constant light and the audible warning will become silent.

Please refer to the “In case of emergency” chapter, and you will find detailed information about recommended action in the “Diagnostic function” section.

The fault will also be stored in the form of a fault code for as long as the malfunction remains. It is possible to read the fault code during a subsequent service.



Cruising speed

Avoid operation at full throttle, for best fuel economy. We recommend a cruising speed which is at least 10% below the maximum engine speed at full speed (full throttle). The maximum engine speed will vary due to propeller choice, load and sea conditions, but it should be in the full throttle range.

Full throttle range:

- D12D-C MH rating 1 1800–1850 rpm.
- rating 2 1900–1950 rpm.

If the engine does not reach the full throttle range, this could be caused by a number of factors which are noted in the “Fault tracing” chapter. If the engine speed exceeds the full throttle range, select a coarser pitch propeller. Ask your Volvo Penta dealer for advice.


Synchronizing engine speed

When driving with twin engines, both the operating economy and comfort will be increased when the engines are operating at the same engine speed (rpm).

When the synchronization function is activated, the engine speed (rpm) of the starboard engine is automatically adjusted to that of the port engine. The synchronization function is activated automatically if the following conditions are met.

1. The engine speed levers for both engines are in (approximately) the same position.
2. The engine speed on both engines must exceed 800 rpm.

NOTE! The synchronizer is disengaged as soon as the conditions are no longer met.



Changing the helm station

The first time you change control panel after starting the EVC system, a bulb check is done automatically. All LEDs and bulbs light up for 2 seconds.


1. Check that the control lever(s) is (are) in neutral on **both** the control panel you leave and on the new control panel.
2. Check that the EVC system is not locked.
3. Press the activation button (1) for at least one second. When the button is released, the indication lights up to confirm that the control position is activated.
4. Press the activation button (1) for a further second to lock the EVC system. The padlock sign lights up in confirmation. Unlock the system by pressing the activation button for one second. This can only be done from an activated control panel.

Changing helm station while cruising (optional)

This function must be enabled to permit the control panel to be changed during operation. The function can only be enabled by authorized Volvo Penta personnel. Please contact your Volvo Penta dealer.

1. Press the activation button (1) to unlock the system. The padlock sign goes out on all control panels to indicate that it is possible to change control panel.
2. The control lever on the alternative control panel must be in neutral before it is possible to change control panel.
3. Press the activation button (1) on the alternative control panel. The activation button indication flashes on the alternative control panel, and on the main control panel it gives constant light.
4. The alternative control panel becomes active when the correct gear and approved engine speed is demanded. The activation button (1) gives constant light to confirm that the control panel is activated. The system is now locked, which is indicated by the padlock sign, which lights up.

NOTE! If the correct gear or engine speed is not demanded within 15 sec, the system ramps engine speed down to neutral and the gearbox engages neutral.



Operation

Shifting between forward and reverse should be done at idling. Shifting at higher engine speeds can be uncomfortable for passengers and cause unnecessary stress on the stern drive/reversing gear, or cause the engine to stop.

If you attempt to shift gear at an excessive engine speed, a safety function cuts in automatically, and delays shifting until engine speed has fallen to 1000 rpm.

Always do a forwards/reverse operation as follows:

1. Reduce engine speed to idle and let the boat more or less lose way.


⚠ WARNING! Never shift to reverse when the boat is planing.

2. Move the control lever to neutral with a rapid, distinct movement. Make a brief pause.

NOTE! A beep will sound to indicate that the control lever is in neutral.

3. Then move the control lever to reverse with a rapid, distinct movement and increase engine speed.


⚠ IMPORTANT! If the boat has twin engines, it is important that both should be running during reversing maneuvers, to avoid the risk of water entry (via the exhaust pipe) into the stationary engine.




Pop-up when Lowspeed is engaged. It is possible to acknowledge pop-up by pushing NAVIGATION WHEEL.



Pop-up when initializing Lowspeed - Lowspeed is not ready to use. (Twin disc)



Lowspeed initializing - Lowspeed is not ready to use. (Twin disc)



Lowspeed activated - Function active.



Pop-up when Lowspeed is disengaged. It is possible to acknowledge pop-up by pushing NAVIGATION WHEEL.

Lowspeed (option)

The Lowspeed function is only available for engines with hydraulic reverse gear.

For boats with powerful engines, where the boat speed at idle is too high, Lowspeed is used to reduce boat speed by reducing propeller rpm - compared to normal at engine idle speed.

N = Neutral idling (reverse gear disengaged, engine runs at idle speed)

F = Forward idling (reverse gear engaged for movement ahead, engine runs at idle speed), maximum slip in reverse gear.

R = Reverse idling (reverse gear engaged for movement astern, engine runs at idle speed), maximum slip in reverse gear.

A = Lowspeed active. Propeller rpm is increased with increase of throttle, engine rpm is not affected.

B = Lowspeed deactivated. Propeller rpm is increased with engine rpm, engine rpm will increase with throttle.

Engaging Lowspeed


1. Move the lever to neutral position.
2. Press the neutral button (N) to activate Lowspeed. When Lowspeed is engaged a pop-up (A) is shown on the tachometer display. It is possible to acknowledge pop-up by pushing NAVIGATION WHEEL.
3. Active Lowspeed is indicated by an icon, **LOW**, on the tachometer display (D).

⚠ IMPORTANT! If Lowspeed initializing pop-up (B) and then icon, **(LOW)**, are shown on the tachometer display (C), Lowspeed is not ready to use. Normal gear shifting until Lowspeed is activated (D).

⚠ IMPORTANT! Delay in gear shifting may occur when Lowspeed is active.

Disengaging Lowspeed

1. Move the lever to neutral position.
2. Press the neutral button (N) to deactivate Lowspeed. A pop-up (E) is shown on the tachometer display. It is possible to acknowledge pop-up by pushing NAVIGATION WHEEL.
3. The indication in tachometer display goes out.



Trolling initializing - Trolling is not ready to use. (Twin disc)



Trolling activated - Function active. Slip control lever in slip position.


Trolling (option)


The Trolling function is only available for engines with hydraulic reverse gear.

Trolling requires two control levers, one for throttle/gear, and the other to control the slip function. Trolling makes it possible to use higher engine power without increasing boat speed.

⚠ WARNING! If engine speed exceeds the maximum permissible engine speed for trolling (approx. 1000 rpm, depending on reverse gear), the EVC system automatically disengages trolling and full propeller effect returns. Depending on the position that the control lever is in when automatic disengagement occurs, the boat speed can increase rapidly.

Operation

Move the throttle/gear lever to a position where the engine speed is within the permissible engine speed range and move the slip control lever to a slip position. Active Trolling is indicated by an icon,  on the tachometer display (B).

⚠ IMPORTANT! If Trolling initializing icon,  is shown on the tachometer display (A), Trolling is not ready to use. Normal gear shifting until Trolling is activated.

NOTE! At maximum slip there is no propeller effect.

Move the slip control lever to minimum slip position to deactivate Trolling. The indication in the tachometer display goes out.

⚠ IMPORTANT! Delay in gear shifting may occur when Trolling is active.

Propeller shaft brake

In certain conditions, the propeller can make the propeller shaft rotate when the engine is stopped. This parasitic rotation is uncomfortable, and can damage the reversing gear since its oil pump, which is driven by the input shaft, is stationary together with the engine.

The propeller shaft can be permitted to rotate with a stationary engine for up to 6-8 h. After this, the engine must be started and run for at least 5 min to lubricate and cool the reversing gear.

If the shaft is likely to rotate faster than in normal operation, such as when sailing, a temperature gauge should be installed to monitor the oil temperature.

Maximum permissible temperature is 95°C for the ZF reversing gear.

When the above-mentioned rules can not be met, or if you want to stop the shaft for comfort reasons, a shaft brake has to be installed. On isolated occasions, the propeller shaft flange can be locked mechanically by some suitable means.



Extra equipment

Disengageable clutch

The clutch is disengaged when the lever is in position (N) and engaged in position (F)

⚠ IMPORTANT! The engine speed must not exceed 800 rprm when engaging and disengaging.

The clutch should be given extra attention during the first period of operation. Adjustment may be required to compensate for disc wear. Refer to "Maintenance: Accessories" when adjusting.



Flush and bilge pump




The bilge pump has a vacuum switch (1) that automatically disengages the pump when water is no longer being drawn into the pump.

The flush and bilge pump are engaged and disengaged from a switch that is normally located at the main control position. The bilge pump can also be engaged manually by holding down the lever 2 for about 20 seconds.

Stopping the engine

Allow the engine to idle (in neutral) for at least three minutes after the end of your journey. This evens out the temperatures inside the engine, and stops after-boiling.

⚠ IMPORTANT! The above is particularly important if the engine has been driven at high speed and/or heavily loaded.



Stop

1. Disengage the reversing gear by putting the control lever in neutral.
2. Turn the key to stop position “S”. Keep the key turned until the engine stops. The key will automatically return to the “0” position when it is released and can then be removed.

⚠ IMPORTANT! Never switch off the main switches while the engine is running. This could damage the alternator.

⚠ IMPORTANT! Never switch off the main switches before the starter key is turned off (is in “0” position or removed). This could damage the electrical system.

Auxiliary stop

If a fault occurs that prevents you stopping the engine in the normal way, you can stop it by pressing the emergency button.

If the engine has been stopped using the emergency stop button, the button locks in the down position. In order to be able to restart the engine, the button must be reset to its original position. To do this, pull the button upwards until you hear a click.

⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.


After stopping

- Check the engine and engine bay for leakage.
- Shut off the fuel taps and sea cocks.

⚠ IMPORTANT! Do not forget to open the taps next time the engine is started.

- Read off the hours counter and do preventive maintenance as in the maintenance schedule.
- Turn off the main switches before any long stoppage.

⚠ IMPORTANT! Never switch off the main switches before the starter key is turned off (is in “0” position or removed). This could damage the electrical system.




Cold weather precautions

If the engine bay can not be kept frost-free, the seawater system must be drained and the freshwater system coolant must have enough anti-freeze to prevent frost damage. Please refer to the “Seawater system” and “Freshwater system” maintenance chapters.

⚠ WARNING! If the engine bay can not be kept frost-free, the seawater system must be drained. Frost damage in the seawater system can make the boat sink.

⚠ IMPORTANT! If the coolant does not have sufficient frost protection, this can cause expensive engine damage. Check the battery charge. A poorly charged battery can freeze and burst.



Laying up

If the boat is not used, but left in the water, the engine must be warmed up at least once every fortnight. This prevents corrosion damage in the engine.

⚠ IMPORTANT! If you expect the boat to be unused for two months or more, it must be laid up: Please refer to the Laying up chapter.

Maintenance schedule


General information


Your Volvo Penta engine and its equipment are designed for high reliability and long life. They are built to withstand a marine environment, but also to have the smallest possible environmental impact. If given preventive maintenance, according to the maintenance schedule, and if Volvo Penta original spares are used, these qualities are retained and unnecessary malfunctions can be avoided.

Warranty inspection

During the first period of operation, the specified warranty inspection "First service inspection" must be done by an authorised Volvo Penta workshop. Instructions about when and where this should be done are found in the **Warranty and service book**.

MAINTENANCE SCHEDULE

 **WARNING!** Before you start to do any maintenance work, read the "Maintenance" chapter carefully. This contains instructions for doing work in a safe and correct manner.

 **IMPORTANT!** When both operation and calendar time are specified, do the maintenance job at the interval which is reached first. Maintenance points marked must be done by an authorised Volvo Penta workshop.

Daily, before first start

- Engine and engine bay. General inspection page 54
- Air filter indicator. Inspection ¹⁾ page 55
- Engine oil. Check level..... page 58
- Coolant. Check level page 63
- Fuel filter. Drain water/contamination page 71
- Reverse gear. Check oil level (after starting) page 81

¹⁾ Change the air filter every 12 months.

After the first 50 hours

- Reverse gear. Oil strainer. Cleaning page 81
- Reverse gear. Oil. Change..... page 82

Every 50 hours / at least every 12 months

- Reverse gear. Seal. Lubrication..... page 82
- Disengageable clutch. Lubrication ¹⁾ page 83

Every 50-500 hours / at least every 12 months

- Engine oil Change ²⁾ page 58
- Oil filter / Bypass filter. Change ³⁾ page 60

¹⁾ Applies to release bearing when operated more than 15 times a day. Otherwise, every 500 operating hours.

²⁾ Oil change intervals vary, depending on oil grade and sulphur content of the fuel. Please refer to page 57.

³⁾ Change the filters during each oil change.

Every 250 hours / at least every 12 months

- Fuel pre-filter (twin filter). Inspection ¹⁾ page 74

¹⁾ Only applies to the double filter: Check the pressure gauge and change the filter as necessary every 1000 hours of operation, or at least once every 12 months.

Every 500 hours / at least every 12 months

- Crankcase ventilation. Change filter page 55
- Drive belts. Inspection/adjustment page 56
- Coolant (corrosion protection mixture). Topping up ¹⁾ page 63
- Zinc anodes. Change page 67
- Seawater pump. Check/change the impeller page 68
- Batteries. Checking the electrolyte page 77

¹⁾ Top up with ½ litre corrosion protection fluid. **IMPORTANT!** This **only** applies if the cooling system is filled with a corrosion protection mixture (**not** a glycol mixture).

Every 1000 hours / at least every 12 months

- Valve clearance. Inspection/adjustment not shown
- Coolant filter. Change ¹⁾ page 65
- Clean the insert in the heat exchanger and in the reverse gear oil cooler not shown
- Seawater filter. Checking/cleaning ²⁾ page 68
- Fuel pre-filter. Change filter insert page 74
- Fuel fine filter. Changing. Venting the fuel system page 70
- Reverse gear. Oil strainer. Cleaning page 81
- Reverse gear. Oil. Change page 82

¹⁾ Not at same time as coolant change.

²⁾ Adjust the time by experience, after a period of operation.

Every 2000 hours

- Turbocharger. Inspection not shown

Every 12 months

- EVC system. Inspection with diagnosis tool not shown
- Engine and reverse gear. General inspection not shown
- Air filter insert. Change page 55
- Flushing/Bilge pump. Check the impeller not shown
- Engine and reverse gear. Cleaning/painting not shown

Every 24 months


- Cooling system Inspection/cleaning not shown
- Coolant. Change page 62

Maintenance


This chapter contains general technical information and instructions for carrying out the specified maintenance points. Read them carefully before starting work. The times when maintenance points need to be attended to are given in the previous chapter: Maintenance schedule

⚠ WARNING! Read through the safety advice for care and maintenance work in the Safety information chapter before you start work.

⚠ WARNING! Care and maintenance work should be done with the engine stopped unless otherwise specified. Stop the engine before opening or removing the engine hatch/hood. Make it impossible to start the engine by removing the start key and cutting the system voltage with the main switches.



Engine, general



General inspection


Make it a habit to give the engine and engine bay a “visual” check before driving **before starting the engine** and after operation **when you have stopped the engine**. This will help you to discover if anything abnormal has happened, or is about to happen.

Look especially carefully at oil, fuel and coolant leakage, loose screws, worn or poorly tensioned drive belts, loose connections, damaged hoses and electrical cables. This inspection only takes a few minutes and can prevent serious malfunctions and expensive repairs.

⚠ WARNING! Deposits of fuel, oils and grease on the engine or in the engine bay are a fire hazard and must be removed as soon as they are discovered.

⚠ IMPORTANT! If you discover a leakage of oil, fuel or coolant, investigate the cause and fix the fault before you start the engine.

⚠ IMPORTANT! Observe the following when cleaning with a high pressure washer: Never aim the water jet at seals, rubber hoses or electrical components. Never use a high pressure washer for engine cleaning.




Crankcase ventilation. Changing the filter

If oil and air begin to find their way out of the over-pressure valve (2), change the filters (1) earlier than recommended.

⚠ IMPORTANT! Change both filters at the same time.

1. Remove the old filters by unscrewing them anti-clockwise.
2. Check the rubber seals, change as necessary. Screw the new filters on by hand.



Air filter. Change

1. If indicator is all **red** after the engine is stopped, change the filter..
2. Undo the clamps and remove the lid from the filter housing.
3. Remove the old filter. Be careful to ensure that no contamination gets into the engine.
4. Install a new air filter and tighten the lid.
5. Reinstall the pressure drop indicator by pressing in the indicator button.

⚠ IMPORTANT! Scrap the old filter. It must not be cleaned.

Drive belts. Inspection/adjustment

⚠ WARNING! Stop the engine before doing any maintenance work.

General information

Check belt tension and condition regularly. A belt which is too tense can damage the bearings and a belt which is too loose can slip.

⚠ IMPORTANT! Always change a belt which looks worn or cracked (belts which operate in pairs must be changed together).

Alternator belt(s)



The standard alternator, plus the extra alternator if installed, are driven by a Poly-Vee belt each, for best function and service life. The belts are tensioned in the same way.

1. Remove the protective cover over the alternator drive belt.
2. Undo the inner fixing screw (1) and the lock screws (2) a couple of turns.
3. Tension the belts with tensioner screw (3). It should be possible to press the belts down about 5 mm (0.2") between the pulleys when the tension is correct.
4. Tighten lock screw (2) and the inner fixing screw (1).
5. Install the protective cover over the alternator drive belt.

Other belts

The flushing and bilge pump etc. are driven by traditional drive belts. In general, it should be possible to press these belts down 10 mm (0.4") between the pulleys when the tension is correct.


When you change a drive belt: Clean the belt grooves before installing the new drive belt.



Lubrication system

Oil change intervals can vary from 50 to 500 hours, depending on oil grade and sulphur content of the fuel. **Note that oil change intervals must never exceed a period of 12 months.**

If you want longer oil change intervals than given in the table below, the condition of the oil must be checked by the oil manufacturers through regular oil testing.



Oil grade ¹⁾	Sulphur content in fuel, by weight		
	up to 0.5%	0.5 – 1.0%	more than 1.0% ²⁾
	Oil change interval: Reached first in operation:		
VDS-3	500 hr. or 12 months.	250 hr. or 12 months.	125 hr. or 12 months.
VDS-2 and ACEA E7 ⁴⁾ or VDS-2 and Global DHD-1 or VDS-2 and API CH-4 or VDS-2 and API CI-4	500 hr. or 12 months.	200 hr. or 12 months.	100 hr. or 12 months.
VDS and ACEA E3 ²⁾ or VDS-2 and API CG-4 ³⁾	300 hr. or 12 months.	150 hr. or 12 months.	75 hr. or 12 months.

NOTE! Mineral based oil, either fully or semi-synthetic, can be used on condition that it complies with the quality requirements above.


¹⁾ When oil quality specifications are joined by "and" the engine oil must fulfill both requirements.

²⁾ If sulphur content is > 1.0% by weight, use oil with TBN > 15.

³⁾ ACEA E7 has replaced ACEA E5, but if available ACEA E5 can be used.

⁴⁾ ACEA E3 can be replaced by ACEA E4, E5 or E7.

VDS = Volvo Drain Specification
 ACEA = Association des Constructeurs Européenne d'Automobiles
 API = American Petroleum Institute
 TBN = Total Base Number
 Global DHD = Global Diesel Heavy Duty



Viscosity


Select the viscosity from the table below.

Note. The temperature values refer to stable ambient temperatures.

* Refers to synthetic or semi-synthetic oils.

Oil change volume

Please refer to the "Technical Data" chapter.



Oil level. Checking and filling

The oil level must be inside the marked area on the dipstick (1) and should be checked daily before the first start.

Top up the oil through the filling hole on the side of the engine (2). Check that the correct level has been achieved. But wait a few minutes to allow the oil to run down into the sump.

⚠ IMPORTANT! Do not fill up above the maximum oil level. Only use a recommended grade of oil (please refer to previous page).

Engine oil. Change

Always observe the recommended oil change interval.

1. Warm the engine up (this makes it easier to suck the oil up from the sump). Then stop the engine.

⚠ WARNING! Hot oil and hot surfaces can cause burns.

2. Connect the suction pipe of the oil drain pipe to the drain pipe. Pump up the oil.
3. Change the oil filter and bypass filter at each oil change (please refer to the instructions on the next page).
4. Fill up with oil to the correct level through the filling hole on the side of the engine (please refer to the "Technical Data" chapter for oil volume).


⚠ IMPORTANT! Only use a recommended grade of oil (please refer to previous page).

5. Start the engine and let it idle. Check that the low oil pressure warning lamp goes out and that no leakage occurs by the filters.

⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.


6. Stop the engine. Wait a few minutes before checking the oil level. Top up as necessary.

NOTE! Hand the old oil in to a re-cycling station.



Switchable oil filters

⚠ IMPORTANT! Though possible, the switchable filters should not be replaced during engine operation other than in case of an emergency




1. Clean the filter bracket.
2. Disconnect the left filter by turning the lever to the right-hand end position. To unlock the lever, pull the knob beneath the lever downwards.
3. Unscrew the left-hand oil filter and discard it. Use a filter wrench if necessary.
4. Check that the mating surfaces on the filter bracket are clean, and that no traces of the seal from the old filter remain.
5. Oil the rubber seal for the new filter.
6. Screw the filter on by hand until the rubber seal just touches the mating surface of the filter bracket. Then tighten the filter a further 3/4 of a turn.
7. Turn the lever to the left-hand end position and change the right-hand oil filter in the same way.
8. Put the lever in operating position (straight up).
9. If necessary, top up the system with lubrication oil at first stop. Refer to section "Lubrication oil change".

Oil filter and bypass filter. Change

Change the oil filter and bypass filter during each oil change.

Remember to hand the old filters in to a re-cycling station.

⚠ WARNING! Hot oil and hot surfaces can cause burns.



1. Put a suitable vessel underneath the filters to avoid oil spillage.
2. Clean the filter bracket.
3. Unscrew the bypass filter (1) and the oil filters (2) with a suitable extractor.
4. Check that the mating surfaces on the filter brackets are clean, and that no residue from the old seals remains.
5. Moisten the seals on the new filters with engine oil.
6. Screw the filters on by hand until the rubber seals just touch the mating surface on the filter brackets. Then tighten a further 1/2 to 3/4 turn.
7. Start the engine (low idle) and check that no leak-

Fresh water system

The fresh water system is the engines' internal cooling system, which ensures that the engine operates at the correct temperature. It is a closed circuit system and must always be filled with a mixture of at least 40 % concentrated coolant and 60 % water to protect against internal corrosion, cavitation and damage caused by freezing.


We recommend that you use “**Volvo Penta Coolant, Ready Mixed**”, alternatively “**Volvo Penta Coolant**” (concentrated) mixed with **pure** water according to spec, see “Coolant. Mixture”. Only coolant of this quality is suited too and approved by Volvo Penta.

The coolant should contain ethylene glycol of a good quality with a suitable chemical consistency for an adequate protection of the engine. Using anti-corrosion additive exclusively is not permitted in Volvo Penta's engines. Never use water by itself as coolant.

⚠ IMPORTANT! Coolant must be used all year round. This applies even if there is never any risk for frost , to ensure that the engine has an adequate protection against corrosion.


Future warranty claims on the engine and additional equipment may be rejected if an unsuitable coolant has been used or if the instructions concerning coolant mixing have not been followed.

NOTE: The anti-corrosive agents become less effective after a time, which means that the coolant must be replaced, see “Service schematic”. The cooling system should be flushed out at the same time as the coolant is replaced, see “Cooling system. Flushing”.



“**Volvo Penta Coolant**” is a concentrated coolant that is to be mixed with water. It has been developed to function optimally with Volvo Penta's engines and provides excellent protection against corrosion, cavitation and frost damage.

“**Volvo Penta Coolant, Ready Mixed**” is a ready-mixed coolant, 40% “Volvo Penta Coolant” and 60% water. This concentration protects the engine against corrosion, cavitation damage and freezing conditions down to -28 °C (-18°F).



Coolant. Mixture

⚠ WARNING! All glycol is hazardous and harmful to the environment. Do not consume!
Glycol is flammable.


⚠ IMPORTANT! Ethylene glycol must not be mixed with other types of glycol.

Mix:
40 % “Volvo Penta Coolant” (conc. coolant)
60 % water

This mixture protects the engine against internal corrosion, cavitation and frost damage down to -28 °C (18°F). (Using 60 % glycol lowers the freezing point to -54 °C (-65°F)). Never mix more than 60 % concentrate (Volvo Penta Coolant) in the cooling liquid, this will give reduced cooling effect and increase the risk of overheating, and will give reduced freezing protection.

⚠ IMPORTANT! Coolant must be mixed with **pure** water, use **distilled - de-ionized water**. The water must fulfill the requirements specified by Volvo Penta, see “Water quality”.


⚠ IMPORTANT! It is extremely important that the correct concentration of coolant is added to the system. Mix in a separate, clean vessel before adding into the cooling system. Ensure that the liquids mix properly.



Water quality

ASTM D4985:

Total solid particles	< 340 ppm
Total hardness:.....	< 9.5° dH
Chloride	< 40 ppm
Sulfate.....	< 100 ppm
pH value.....	5,5–9
Silica (acc. ASTM D859).....	< 20 mg SiO ₂ /l
Iron (acc. ASTM D1068).....	< 0.10 ppm
Manganese (acc. ASTM D858).....	< 0.05 ppm
Conductivity (acc. ASTM D1125).....	< 500 µS/cm
Organic content, COD _{mn} (acc. ISO8467)	< 15 mg KMnO ₄ /l



Coolant level. Inspection


Note. Coolant level can be checked through a level glass on top of the expansion tank.

The green float must be visible in the level glass.

⚠ WARNING! Never open the pressure cap when the engine is hot. Steam or hot coolant can spray out at the same time as the pressure which has built up is lost.

The coolant level should be about five centimetres (2") below the pressure cap sealing plane in the expansion tank.

If a separate expansion tank is installed, the coolant level must be between the MAX and MIN markings. Top up the coolant as necessary, following the description below.



Coolant. Filling

⚠ WARNING! Stop the engine and let it cool before filling. Hot fluids and hot surfaces can cause burns.

⚠ IMPORTANT! Top up with the same type of coolant as already used in the system.


Topping up


Fill up with coolant to the correct level via the filling hole on the expansion tank. Fill slowly, to allow the air which is forced out a chance to flow out of the filling hole.

When you fill up an empty system, or if the coolant has fallen so low for any reason that it is no longer visible through the filling hole, fill up as in the description for "Filling a completely empty system".


Filling a completely empty system

1. Mix a sufficient quantity of coolant in a vessel before filling. Please note that a heating system, tap water heater etc. if connected to the engine cooling system, mean that a correspondingly greater amount of coolant will be needed.
2. Open the vent tap by the turbocharger.
3. Also ensure that the heating system, tap water heater etc. if connected to the engine cooling system, are also vented (open the heater control valve).





4. Fill up with coolant via the filling hole on the expansion tank.
Fill slowly, to allow the air which is forced out a chance to flow out of the vent tap(s) and filling hole.
5. Close the vent tap(s) as and when air-free coolant flows out.
6. Fill up with coolant to about 5 cm (2") below the filling cap seal plane.
7. Start the engine and let it idle for about 1 hour.
⚠ IMPORTANT! Do not start the engine until the system is vented and completely filled.
8. Stop the engine and let it cool. Check the coolant level. Top up as necessary.





Coolant. Draining.

⚠ WARNING! Stop the engine and let it cool before draining. Hot fluids and hot surfaces can cause burns.

⚠ WARNING! Glycol is poisonous (dangerous to drink). Collect the old coolant and hand it to a re-cycling station for destruction. Drain the coolant via taps (F).

1. Remove the filling cap (1) from the expansion tank.
2. Open the vent tap (V) by the turbocharger.
3. Connect a suitable hose to each drain tap. Open the tap and allow the coolant to drain off into a suitable vessel.
⚠ IMPORTANT! Check that all coolant really does drain out. Deposits may need to be cleared away, inside the drain plug(s)/tap(s).
4. Continue with all the drain points until all five have been opened and all coolant has been drained off.
5. Also drain the heating system, tap water heater etc., if connected to the engine's freshwater system.
6. Close all drain taps.



Freshwater system. Flushing


The cooling system should be flushed when the coolant is changed, to avoid loss of cooling performance due to deposits in the cooling system.

1. Drain the coolant, as in the description on the previous page.
2. Put a hose into the filling hole in the heat exchanger and flush with fresh water.
3. Flush until the water which runs out of the drain points is clean.
4. Close all drain points when all coolant has run out.
5. Fill up with coolant, as in the description on the previous page.

Coolant filter. Change

⚠ IMPORTANT! Do **not** change the filter when the coolant is changed. The concentration of rust-preventer in the coolant can become too high, which would cause foaming and impaired cooling.

⚠ WARNING! Hot coolant and hot surfaces can cause burns.





1. Clean the filter bracket.
2. Close the filter tap (1), (position A).
3. Unscrew the filter with a suitable extractor.
4. Clean the filter mating surface on the filter bracket.
5. Moisten the seals on the new filter with engine oil and screw the filter on by hand until the rubber seal just touches the mating surface on the filter bracket. Then tighten a further 1/2 turn.
6. Open the filter tap (1), (position B).
7. Start the engine and check carefully that no leak-

Seawater system

The seawater system is the engine's external cooling system. The seawater system sucks in water through the seawater inlet and pumps it through the heat exchanger and the reverse gear oil cooler. The system is protected from galvanic corrosion by means of zinc anodes located in the heat exchanger and the reverse gear oil cooler.

⚠ WARNING! There is a risk of water entry when you do any work on the seawater system (if the boat is in the water). If any hose, plug etc. located below the waterline is removed, water will flow into the boat. **Always close the sea cocks.** If the boat does not have sea cocks, the water flow must be blocked in a safe manner. If this is not possible, the boat must be drawn up on land before work starts.



Seawater system. Draining.

The seawater system must be drained in cold weather, if there is a risk of frost, to prevent frost damage.

⚠ WARNING! Risk of water entry. Close the seawater cocks before doing any work on the seawater system.

An alternative to draining is to keep the engine bay above freezing temperature, by means of a fan heater which is approved for outdoor use.

Draining:



1. Close the sea cock.
2. Connect a hose to each drain tap before opening the tap (one at a time).
3. Open the drain taps/remove the drain plugs (S) and allow the water to run out.

Drain points:

- tap on reverse gear oil cooler
- tap at rear of heat exchanger
- tap above seawater pump
- plug below seawater pump

⚠ IMPORTANT! Check that all water really does drain out. Deposits may need to be cleared away, inside the drain plug/tap.

4. Also drain/empty any auxiliary equipment such as the seawater filter, flushing/bilge pump etc.
5. Install the lid on the flushing/bilge pump if fitted. Connect all hoses.
6. Close/install all drain taps and plugs before you leave the boat.




Zinc anodes. Check/change

⚠ WARNING! Risk of water entry. Close the sea cock before doing any work on the seawater system.

1. Close the sea cock.
2. Open the drain tap (1) on the reverse gear oil cooler, and the tap (2) on the heat exchanger, and drain off the seawater.
3. Remove the zinc anodes (Z) in the heat exchanger (2 pcs.) and in the reverse gear oil cooler (2 pcs).
4. Check the zinc anodes and replace them if more than 50% of their original size has been used up. If not, clean the zinc anodes with emery cloth to remove the oxide layer before re-installing them.

⚠ IMPORTANT! Use an emery cloth for cleaning. Do not use steel tools, since this could impair the galvanic protection.

5. Install the zinc anodes. Make sure that good metallic contact is obtained between the anode and the casting.
6. Close the drain taps (1 and 2).
7. Open the sea cock before starting the engine.
8. Check that no leakage occurs.




Impeller. Check/change

⚠ WARNING! Risk of water entry. Close the sea cock before doing any work on the seawater system.

1. Remove the seawater pump lid, and pull the impeller out with water pump pliers.
2. Check the impeller. If any cracks or other defects are visible, the impeller must be changed.
3. Lubricate the pump housing and the inside of the lid with water-resistant grease (which is not aggressive to rubber). The impeller will be easier to work with if it is put in hot water prior to fitting.
4. Press the impeller in with a circular motion (counter clockwise). The shaft of the pump has an internal thread (M8). Screw a stud into the end of the shaft and press the impeller in using a washer and nut. Fit the cover, using a new O-ring.
5. Open the sea cock.

⚠ IMPORTANT! Always carry a spare impeller on board.




Seawater filter. Inspection/cleaning

The seawater filter is optional equipment.

If the water where the boat is operated contains a lot of contamination, weed etc., check the filter more frequently than specified in the maintenance schedule. There is otherwise a risk that the filter would be blocked, which would make the engine overheat.

⚠ WARNING! Risk of water entry. Close the seawater cock before doing any work on the seawater system.

1. Close the sea cock.
2. Remove the lid (1) and lift up the insert.
3. Clean the insert and the housing (2).
4. Install the components as in the illustration. Check the O-ring. Change as necessary.
5. Open the sea cock and check carefully that no leakage occurs.



Inlet manifold. Checking the drain hole

Water can condense in the aftercooler during operation. The condensate is drained via a hose connected to a nipple under the rear of the inlet manifold.

Check that the nipple is not blocked.

⚠ WARNING! If a large amount of water flows out of the drain hole, from the inlet manifold, the aftercooler must be removed and proof tested.

This task must be done by an authorised workshop.


Fuel system

Only use the grades of fuel recommended in the fuel specification, see Technical Data. Always observe the greatest cleanliness during re-fuelling and work on the fuel system.

All work on the unit injectors of the engine must be carried out by an authorised workshop.

⚠ WARNING! Fire hazard. Work on the fuel system must be carried out when the engine is cold. Fuel spills on hot surfaces or electrical components can cause fires. Store fuel-soaked rags and other flammable material in fireproof conditions.

⚠ WARNING! Hot fuel can cause burns.




Fuel system venting

The fuel system must be vented, e.g. after changing fuel filter, if the fuel tank has been run dry and after long stops.

Single filter and Switchable filters

Stationary engine:

1. Put a suitable vessel underneath the fuel filter.
2. Remove the protective cap from the venting nipple (1) on the filter bracket. Connect a transparent plastic hose to the nipple and lower this into the vessel.
3. Open the venting nipple and pump up fuel with the hand pump (2) until air-free fuel flows out. Tighten the venting nipple while fuel is flowing out. Repeat with the second switchable filter.
4. Remove the hose and put the protective cap back on the venting nipple.
5. If the tank has been run dry or if the engine, for some reason, has been emptied of fuel, open the venting nipple (3) at the front of the engine block and vent in the same way.
6. Run the engine at idling speed for a couple of minutes to allow any remaining air out of the system. Then close the vent (3) on the engine and make sure there are no leaks.




Fuel filter

Drain

⚠ WARNING! Hot fuel can cause burns.



Stationary engine:

1. Put a suitable vessel underneath the filter.
2. Open the tap (1) and drain water and contamination from the water trap (2) by pumping with the hand pump (3) until clean fuel flows out.



Running engine (switchable filters only):

1. Shut off the fuel flow to the filter to be drained (A).
2. Put a suitable vessel underneath the filter.
3. Cautiously open the tap (1).
4. Drain water and contamination from the water trap by turning the handle to venting position (B). Tighten the venting nipple when clean fuel flows out.
5. Repeat with the other filter.
6. Turn the handle to normal operating position (N).



Change the filter elements



Stationary engine:

(Single and switchable filters)

1. Close the fuel valve/valves.
2. Clean the filter bracket and put a suitable vessel under the filter.
3. Relieve pressure inside the filter by first opening the drain tap (1) at the bottom of the water trap and then the venting nipple (2) to drain the filter of fuel.

⚠ WARNING! High pressure, open the tap with caution. Hot fuel can spray out in any direction.

4. Remove the cables (3) from the water trap (4) and unscrew the water trap from the filter.
5. Unscrew the filter, use a filter wrench if needed.




6. Clean the sealing surfaces of the filter bracket. Make sure the filter is absolutely clean and the sealing surfaces are undamaged. Moisten the sealing rings with engine oil, including the inner rubber seal located inside the threaded hole in the center of the filter.

NOTE! Do not fill the new filter with fuel before assembly. Contaminations may get into the system and cause damage and malfunction.

7. Screw the new filter on by hand until the seal just touches the mating surface. Then tighten a further 1/2 turn. Reinstall the water trap and the cables. Close the drain tap.
8. Open the fuel valve.
9. Open the venting nipple and pump up fuel with the hand pump (5) until air-free fuel flows out. Tighten the venting nipple while fuel is flowing out.
10. Remove the hose and put the protective cap back on the venting nipple.
11. Start the engine and check for leakages.

Change the filter elements

Running engine (switchable filters only):



⚠ WARNING! Hot fuel can cause burns.


1. Clean the filter bracket and put a suitable vessel under the filter.
2. Remove the protective cap from the venting nipple (1) on the filter bracket. Connect a transparent plastic hose to the nipple and lower this into the vessel.
3. Shut off the fuel flow to one of the filters by lifting the handle (2) and turning it to its end position (A).
4. Remove the cables (3) from the water trap (4) on the shut off filter.
5. Relieve pressure inside the filter by first opening the drain tap (5) at the bottom of the water trap and then the venting nipple to drain the filter of fuel.

⚠ WARNING! High pressure, open the tap with caution. Hot fuel can spray out in any direction.

6. Unscrew the water trap and filter, use a filter wrench if needed.
7. Clean the sealing surfaces of the filter bracket. Make sure the filter is absolutely clean and the sealing surfaces are undamaged. Moisten the sealing rings with engine oil, including the inner rubber seal located inside the threaded hole in the center of the filter.

NOTE! Do not fill the new filter with fuel before assembly. Contaminations may get into the system and cause damage and malfunction.

8. Screw the new filter on by hand until the seal just touches the mating surface. Then tighten a further 1/2 turn. Reinstall the water trap and the cables. Close the drain tap.
9. Vent by turning the handle (2) to venting position (B). This allows a reduced flow of fuel through the filter and evacuates air through the vent. Tighten the venting nipple when air-free fuel flows out.
10. Remove the hose and put the protective cap back on the venting nipple.
11. Repeat with the other filter.
12. Turn the handle to normal operating position (N). Check for leakages.



Fuel pre-filter


The fuel pre-filter supplied by Volvo Penta is available in single and twin versions.

Fuel pre-filter. Inspection

This filter is equipped with a pressure gauge (1) which indicates when it is time to change the filter insert.


Change the filter inserts as recommended in the maintenance schedule, or earlier if the pressure gauge shows a negative pressure of 6-10 (in. Hg) at idle or 16-20 (in. Hg) at full speed/loaded engine.

⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.



Drain

Place a receptacle under the filter. Drain off water and contaminants through the plug (4).




Fuel pre-filter. Changing the filter insert

The fuel pre-filter/water trap supplied by Volvo Penta is available in single and twin versions. The twin filter inserts can be changed with the engine running, by closing off fuel flow to one filter housing at a time.

Fuel flow is controlled by putting the handle (1) in the following positions:

- A:** Normal operation (both filters are connected).
- B:** The left filter insert can be changed.
- C:** The right filter insert can be changed.
- D:** Both filters shut off.



Change the filter elements


If the engine is not running close the fuel cocks on the tank before changing filters. If the engine is running cut off the flow of fuel with the handle (1) on the filter itself.

1. Place a receptacle under the filters and shut off the filter to be changed.
2. Undo the T-bolt (2) and remove the cover (3).
3. Take out the insert carefully while turning it.
4. Drain off water and contaminants through the drain plug (4).
5. Fit a new filter insert and fill the container with clean fuel.
6. Change the gasket on the cover and the O-ring on the T-bolt. Moisten the gasket and O-ring with fuel before assembling.
7. Fit the cover and tighten it by hand.
8. Wipe off any fuel from the heat shield.
9. Change the other filter in the same way.
10. Open the fuel cocks and put the handle in position for normal running. Make sure there are no leaks.

Electrical system

The engine is equipped with a 2-pole electrical system and an alternator. System voltage is 24V.


⚠ WARNING! Before any work is done on the electrical system, the engine must be stopped and the current cut by switching off the battery isolator. Shore current for engine heaters, battery chargers or other auxiliary equipment connected to the engine must be disconnected.



Main switches

The main switches must never be disconnected before the engine has been stopped. If the circuit between the alternator and the batteries is disconnected when the engine is running, the alternator and electronics can be damaged. The charging circuits must never be re-connected with the engine running, for the same reason.

⚠ IMPORTANT! Never disconnect the current with the main switches when the engine is running.



Electrical connections




Check that electrical connections are dry, free from oxide and that they are securely tightened. Spray these connections as necessary with water-repellent spray (Volvo Penta universal oil).

Batteries. Maintenance

⚠ WARNING! Fire and explosion hazard. Batteries must never be exposed to open flames or sparks.

⚠ WARNING! Never confuse the positive and negative poles on the batteries. Risk of arcing and explosion.

⚠ WARNING! Battery electrolyte is highly corrosive. Always protect your eyes, skin and clothes when handling batteries. Always use protective goggles and gloves. If acid comes into contact with your skin, wash at once with soap and a lot of water. If you get battery acid in your eyes, flush at once with a lot of water, and get medical assistance at once.



Connection and disconnection

When you connect batteries, first connect the + cable (red) to the + pole on the battery. Then connect the – cable (black) to the – pole on the battery

When you disconnect batteries, disconnect the – cable (black) first, then the + cable (red).

Cleaning

Keep the batteries dry and clean. Contamination and oxide on the batteries and battery poles can cause stray currents, voltage drop and discharge, especially in wet weather. Clean oxidation from the battery poles and terminals, using a copper brush. Tighten the terminals securely and grease them with terminal grease or Vaseline.

Electrolyte level

The electrolyte level should be 5–10 mm (0.2–0.4”) above the cell plates in the battery. Top up with battery water as necessary. After topping up, the batteries should be charged by connecting them to a battery charger, or by running the engine at normal speed for 30 minutes.

NOTE! Some maintenance-free batteries have special instructions, which must be observed.

⚠ IMPORTANT! Never confuse the positive and negative poles on the batteries.



Batteries. Charging

⚠ WARNING! Explosion risk! Hydrogen is given off when batteries are charged. This forms an explosive mixture with air. A short circuit, open flame or spark could cause a violent explosion. Ventilate well.

⚠ WARNING! Battery electrolyte is highly corrosive. Protect your eyes, skin and clothes. Always use protective goggles and gloves. If acid comes into contact with your skin, wash at once with soap and a lot of water. If you get battery acid in your eyes, flush at once with a lot of water, and get medical assistance at once.


Charge batteries if they have become discharged. If the boat is not used for a longer period of time, the batteries should be fully charged, then trickle charged (please refer to the battery manufacturer's recommendations). Batteries are damaged by being left discharged, and can also freeze and burst easier in cold weather.


⚠ IMPORTANT! Observe the instruction manual for the battery charger carefully. To avoid the risk of electrochemical corrosion when an external charger is connected, the battery cables in the boat should be removed from the batteries before the charger is connected.

During charging, unscrew the cell plugs but leave them in the plug holes. Ventilate well, especially if the batteries are charged in an enclosed space.

⚠ WARNING! Always switch off the charge current before undoing the charging clamps. Never confuse the positive and negative poles on the batteries. Risk of arcing and explosion.

Special instructions apply to so-called **quick chargers**. Quick charging can shorten battery life, and should therefore be avoided.





Electric welding

Remove the positive and negative cables from the batteries. Then disconnect all cables connected to the alternator.

Also undo the two connectors for the EVC system from the control unit. Press the lock tab down and pull the connector out.


Always connect the welder earth clamp to the component to be welded, and as close as possible to the weld site. The clamp must never be connected to the engine or in such a way that current can pass through a bearing.

⚠ IMPORTANT! After you have finished welding, re-connect the EVC connector and the alternator terminals **before** you connect the battery cables.

Electrical installations


An incorrectly done electrical installation can generate stray currents from the electrical system. Stray currents, in their turn, can weaken the galvanic protection of the propeller, propeller shaft, rudder, keel etc., and cause damage because of electrochemical corrosion.

⚠ IMPORTANT! Work on the low voltage circuits in the boats should be done by a person with electrical training or knowledge. Installation or work on land current equipment **must only** be done by a competent electrician, in accordance with local regulations for mains electricity.



Always consider the following:

1. If land current is connected, its protective earth must be connected ashore, never to the boat. The land current installation must also be provided with an earth fault breaker (RCCB). The land current installation (transformer, inverter, battery charger etc.) must be intended for marine use, **where the high voltage section is galvanically isolated from the low voltage section.**
2. Electrical cables must be installed and clamped in such a way that they are not exposed to chafing, damp or splashing water in the bilge.




3. Protective earth cables for radio, navigation equipment, rudder, bathing steps etc., or other equipment which uses protective earthing, shall be connected to a common earthing point which is not connected to the engine or reverse gear.

⚠ IMPORTANT! The engine and reverse gear must never be used as earth planes.

4. The starter battery shall have a main switch on the positive (+) side of the battery. The main switch must disconnect all loads and shall be switched off when the boat is not used.
5. If an extra auxiliary battery is used, a main switch (1) must be connected between the auxiliary battery positive (+) pole and the fuse box for the boat's electrical equipment. The main switch must disconnect all loads connected to the auxiliary battery and shall be switched off when the loads are not used. All equipment connected to the auxiliary battery shall have separate switches.

A charge splitter (optional) should be installed to charge two independent battery circuits from the standard alternator.

Reverse gear



Oil level. Checking and filling

Inspection

Check the oil level when the reverse gear has reached operating temperature, with the engine idling and the control lever in neutral.


⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.

Remove the dipstick (1), wipe it off and put it back into the reverse gear. Remove the dipstick again and check the oil level. The correct oil level is between the MAX and MIN marks.

Filling

If necessary, top up with oil through the filler hole (2) on top of the reverse gear. Oil grade and volume: Please refer to the "Technical Data" chapter.

⚠ IMPORTANT! Never over-fill the reverse gear. The oil level must always be within the recommended range.




Oil strainer. Cleaning

⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.

1. Remove the lid/plug and carefully remove the strainer (1) from the housing.

⚠ IMPORTANT! Cleanliness! Dirt must not be allowed to get into the reverse gear.

2. Clean the strainer and other components in paraffin (kerosene).
3. Carefully put the components back again.
4. Tighten the plug/screw.
5. Start the engine and check carefully that no leakage occurs




Oil. Change

1. Remove the dipstick. Connect a hose from the oil scavenging pump to the dipstick tube.
2. Suck the oil up and put the dipstick back.
3. Fill up with oil to the correct level. Oil grade and volume: Please refer to the "Technical Data" chapter.

⚠ IMPORTANT! Never over-fill the reverse gear.

4. Start the engine and run until the reverse gear has reached operating temperature.
5. Check the oil level, as in the description on the previous page.



Seal. Lubrication


Applies only to TwinDisc reverse gear

Lubricate the seal on the output shaft bearing (with the lubricating nipple) using a hand gun and lithium-based grease such as Mobilux EP2, Statoil Uniway EP2N, Texaco Multifak EP2, Q8 Rembrandt EP2.

Accessories

Disengageable clutch. Adjusting

Stop the engine and put the clutch lever in neutral. Remove the inspection hatch and turn the clutch until the locking device on the adjusting ring is accessible. The locking devices have slightly different appearances depending on the make (see illustrations).




Twin Disc (T.D.)

1. Press the locking pin (A) and turn the adjusting ring (B) to the right enough notches so that a torque of 218 Nm (161 lbf.ft.) is required on the lever for engagement.
2. Screw on the inspection hatch.

Disengageable clutch. Lubrication


Use lithium-based grease such as Mobilux EP2, Statoil Uniway EP2N, Texaco Multifac EP2, Q8 Rembrandt EP2.



Main bearing and clutch mechanism

Lubricate the inner support bearing (with lubricating nipple), the main bearings, release shaft and the moving parts in the clutch mechanism with grease. Lubricate sparingly, 20–30 grams (0.6–1.0 oz) for the main bearings.

Lubricate the inner link arms with a few drops of oil.



Release bearing

Lubricate sparingly so the grease is not forced out. Use grease complying with the recommendations above.

⚠ IMPORTANT! If operated more than 15–20 times a day, the release bearing must be lubricated every 50 operating hours. Otherwise, every 500 operating hours.

Laying up/Launching

The boat must be laid up to prevent damage to the engine and other equipment if the boat is not used for two months or more. It is important that this is done in the correct manner, and nothing is forgotten. For this reason, we have compiled a check list of the most important points.

Before the boat is taken out of service for a long period of time, an authorised Volvo Penta workshop should over the engine and other equipment. Have any faults and deficiencies attended to, so that the equipment is in order, ready for the next start.


⚠ WARNING! Before you start to do any maintenance work, read the “Maintenance” chapter carefully. This contains instructions for doing work in a safe and correct manner.

Some conservation oils are flammable. Some are also dangerous to breathe. Ensure good ventilation. Use a face mask when spraying.

⚠ IMPORTANT! Observe the following when cleaning with a high pressure washer: Never aim the water jet at seals, rubber hoses or electrical components. Never use a high pressure washer for engine cleaning.

Inhibiting


- Warm the engine up to normal operating temperature and check that the oil level in the reverse gear reaches the MAX mark on the dipstick. Stop the engine.
- **Max 8 month’s stoppage:**
Change the oil and oil filter on the engine, then warm it up afterwards.
- **More than 8 month’s stoppage:**
Conserve the lubrication and fuel systems with conservation oil. **Please refer to the instruction on the next page.**
- Check that the coolant offers sufficient frost protection. Top up as necessary. Alternatively, you can drain the coolant (also drain the coolant filter).
- Close the sea cock and drain the water from the seawater system.
- Remove the impeller from the seawater pump. Store the impeller in a sealed plastic bag, in a cool place.
- Drain any water and contamination from the fuel filters and fuel tank. Fill the fuel tank completely, to avoid condensation.
- Disconnect the battery cables, clean and charge the batteries. Trickle charge the batteries while the boat is laid up. **A poorly charged battery can freeze and burst.**
- Clean the outside of the battery. Do not use a high pressure washer for engine cleaning. Touch up paint damage with Volvo Penta original paint.
- Spray the components of the electrical system with water-repellent spray (Volvo Penta universal oil).
- Check and rust-proof any control cables.
- Put a note on the engine with the date, type of conservation and the conservation oil used.
- Cover over the engine air inlet, exhaust opening and engine if necessary.



Bringing out of storage

- Remove any covers from the engine, air inlet and exhaust pipe.
- Top the engine up with the correct grade of oil, if necessary. Install a new oil filter if the filter was not changed during conservation.
- Check that there is oil in the reverse gear.
- Install new fuel filters and vent the fuel system.
- Check the drive belt(s).
- Check the condition of all rubber hoses, and re-tighten the hose clamps.
- Close the drain taps and install the drain plugs.
- Insert the impeller in the seawater pump, using a rotating movement (anti-clockwise).
- Check the coolant level and anti-freeze. Top up as necessary.
- Connect the fully charged batteries.
- Open the sea cocks
- Start the engine (if the boat is in the water) and warm up at a fast idle before loading the engine.
- Check that no oil, fuel or coolant leakage occurs.
- Check the oil level in the reverse gear. Top up as necessary.

Conservation of the lubrication and fuel systems for more than 8 months' stoppage:



- Drain the oil from the sump and engine and fill the engine up with **conservation oil*** to just above the MIN marking on the dipstick.
- Connect the fuel supply (1) and return fuel pipes (2) to a jerrican filled with 1/3 **conservation oil*** and 2/3 diesel fuel.
- Vent the fuel system.
- Start the engine and run at a fast idle until about 2 litres (0.5 US gal.) have been used. Stop the engine and connect the ordinary fuel pipes.
- Empty the conservation oil out of the engine
- Follow the other instructions on the previous page.

* Conservation oils are sold by oil companies.

In case of emergency

Despite regular maintenance according to the maintenance schedule and perfect operation, it may occur that a fault occurs which must be attended to before the boat can travel further. This chapter contains tips for rectifying some of the possible faults.

There are safety functions which are activated when certain faults occur, to protect the engine. The following can occur:

- Engine can not be started
- Reversing gear in neutral and engine speed is limited to 1000-1200 rpm, depending on engine.
- The engine stops

If fault occurs, acknowledge any alarm and take the recommended measures. Please refer to this chapter and the "Fault register" chapter.



Starting with auxiliary batteries

⚠ WARNING! Ventilate well. Batteries contain and give off an explosive gas which is highly flammable and explosive. A short circuit, open flame or spark could cause a violent explosion.

⚠ WARNING! Never confuse the positive and negative poles on the batteries. Risk of arcing and explosion.

1. Check that the rated voltage of the help start battery is the same as the system voltage of the engine.
2. Connect the red jumper cable to the positive pole (+) of the flat battery, and then to the positive pole of the help start battery.
3. Connect the black jumper cable to the **negative pole (-)** of the help start battery, and then to a place some distance from the flat batteries, such as the negative connection on the starter motor.

WARNING! Under no circumstances may the black jumper cable (-) come into contact with the positive connection on the starter motor.

4. Start the engine and run at a fast idle for about ten minutes to charge the batteries.

⚠ WARNING! Working with, or going close to a running engine is a safety risk. Watch out for rotating components and hot surfaces.

⚠ WARNING! Do not touch the connections during the start attempt: Risk of arcing. Do not stand bending over any of the batteries either.


5. Stop the engine. Remove the jumper cables in the exact reverse order from installation.

Emergency shifting

If a fault occurs which prevents the revers gear from being operated (shifted) with the control lever, it is possible to shift manually, using the description below.

Note. The descriptions refer to electrically shifted revers gear.

⚠ WARNING! In emergency shifting, the unit is locked in forwards operation. Please note that the revers gear can not then be disengaged with the control lever. Forward motion can only be cut off by stopping the engine with the ignition key or stop button.



1. Stop the engine and remove the start key from the key switch.
2. Note the valve (P or S) to which the cable marked "Primary" is connected. Then undo the connectors (1 and 2) from the solenoid valves.
3. Remove the cap nut from the valve which was connected to the "Primary" cable.
4. Press the valve (A) on the valve.
5. Turn the button a 1/2 turn **anti-clockwise** (the button is forced out by spring action). The reverse gear is now connected for forward motion and cannot be disengaged by the control lever.

Fault-tracing

A number of symptoms and possible causes of engine malfunctions are described in the table below. Always contact your Volvo Penta dealer if problems occur which you can not solve by yourself.

⚠ WARNING! Read through the safety advice for care and maintenance work in the “Safety information” chapter before starting work.

Symptoms and possible causes	
Pop-ups are shown in the tachometer display	See the “Fault register” chapter
Engine can not be stopped	2, 4, 5, 7
Starter motor does not rotate	1, 2, 3, 4, 5, 6, 8, 9, 10, 11, 36, 38, 39
Starter motor rotates slowly	1, 2
Starter motor rotates normally but engine does not start	12, 13, 14, 15, 38
Engine starts but stops again	12, 13, 14, 15, 19, 38
Engine does not reach full operating speed at full throttle	13, 14, 15, 16, 17, 18, 19, 20, 23, 33, 37, 38
Engine runs unevenly	14, 15
Engine vibrates	24
High fuel consumption	16, 17, 21
Black exhaust smoke	19
Blue or white exhaust smoke	20, 21, 34
Lubrication oil pressure too low	22
Coolant temperature too high	25, 26, 27, 28, 29, 30, 31, 32
Coolant temperature too low	31
No charge or poor charge	2, 35

- | | | |
|---|---|---|
| 1. Flat batteries | 14. Air in the fuel system | 26. Air in the freshwater system |
| 2. Poor contact/open circuit in cables | 15. Water/contamination in fuel | 27. Faulty circulation pump |
| 3. Main switch turned off | 16. Boat abnormally loaded | 28. Closed seawater inlet |
| 4. One of the circuit breakers in the distribution box has tripped. | 17. Fouling on hull/propeller | 29. Blocked seawater inlet/pipe/filter |
| 5. Faulty key switch | 18. Faulty injectors (nozzles) | 30. Defective impeller in seawater pump |
| 6. Control lever not in neutral/control position not activated | 19. Insufficient air supply to engine: | 31. Defective thermostat |
| 7. Faulty stop relay | – blocked air filter | 32. Blocked heat exchanger insert |
| 8. Faulty main relay | – air leakage between turbocharger and engine inlet pipe. | 33. Blocked aftercooler |
| 9. Faulty starter relay | – fouled compressor section in turbocharger | 34. Too high oil level |
| 10. Faulty starter motor relay | – faulty turbocharger | 35. Alternator drive belt slips |
| 11. Faulty starter motor/solenoid | – poor engine bay ventilation | 36. Water entry into engine |
| 12. Lack of fuel: | 20. Excessive coolant temperature | 37. High back pressure in exhaust system |
| – fuel taps closed | 21. Too low coolant temperature | 38. Stored fault codes* |
| – fuel tank empty/wrong tank connected | 22. Too low oil level | 39. Check that the emergency stop button is in the running position (not pressed down). |
| 13. Blocked fine fuel filter/pre-filter (caused by contamination or fuel stratification at low temperature) | 23. Faulty / wrong propeller | |
| | 24. Faulty engine mounting | |
| | 25. Coolant level too low | |

* **NOTE!** The codes can only be read and erased by a service technician.

Diagnostic function

The diagnostic function monitors and checks that the engine, stern drive/reverse gear and EVC system function normally.

The diagnostic function has the following tasks:

- Discover and localize malfunctions
- Notify that malfunctions have been discovered
- Give advice in fault finding
- Protect the engine and ensure continued operation when serious malfunctions are discovered.

The diagnostic function affects the engine in the following ways when:

1. The diagnostic function has discovered a minor malfunction which does not damage the engine.

Reaction: The engine is not affected.

2. The diagnostic function has discovered a serious malfunction which will not immediately damage the engine (e.g. high coolant temperature):

Reaction: Engine power is reduced till the relevant value is normalized.

3. The diagnostic function has discovered a serious malfunction which will cause serious engine damage.

Reaction: Engine power is reduced.

4. The diagnostic function has discovered a serious malfunction which makes it impossible to control the engine.

Reaction: The reversing gear/drive is disengaged and engine speed is cut to 1000 rpm.

It is possible to do an emergency shift: Please refer to the "Emergency shifting" section.

5. The diagnostic function has discovered a serious malfunction on the sterndrive shift mechanism or in the engine fuel injection system.

Reaction: Engine is stopped

It is possible to do an emergency shift: Please refer to the "Emergency shifting" section. In serious emergency it is also possible to start the engine with gear engaged after acknowledging the alarm.

Malfunction message engine and EVC-system

If the diagnostic function discovers a malfunction, it warns the driver by showing pop-ups in the tachometer display and the buzzer will sound.

Pop-ups will alternate between “cause of fault” and “measures to take”.

To acknowledge the alarm, press NAVIGATION WHEEL. When the fault has been acknowledged, the buzzer will become silent. Press NAVIGATION WHEEL. The pop-up will disappear and normal display window will be shown.

NOTE! To enable engine start the alarm must be acknowledged.



Danger pop-up

If the Danger pop-up is shown during operation, a serious fault has occurred.

NOTE! Acknowledge the alarm and stop the engine at once.

Information regarding “cause of fault” and “measures to take” is found in chapter “Fault register”.

Warning pop-up

If the Warning pop-up is shown during operation, a fault has occurred.

NOTE! Acknowledge the alarm and stop the engine at once.

Information regarding “cause of fault” and “measures to take” is found in chapter “Fault register”.

Caution pop-up

If the Caution pop-up is shown during operation, a fault has occurred.

Acknowledge the alarm.

Information regarding “cause of fault” and “measures to take” is found in chapter “Fault register”.



Faults are stored and malfunctions have been registered

Faults list

A faults list can be viewed from the MAIN MENU, if a fault is registered.

When in MAIN MENU, select FAULTS by pushing NAVIGATION WHEEL. Number after FAULTS indicates number of faults stored in faults list. Show faults in faults list by turning NAVIGATION WHEEL.

Shown fault pop-ups will alternate between “cause of fault” and “measures to take”.

More information regarding “cause of fault” and “measures to take” is found in chapter “Fault register”.

Erasing faults in faults list

Any fault pop-up in the diagnostic function are automatically erased every time the starter key is turned to the stop position (S).

NOTE! Stop the engine and check that the ignition key(s) is(are) in position 0 in all control positions.

When system voltage is switched on again, the diagnostic function checks to see whether there are any faults in the EVC system. If this is the case, new fault pop-ups are shown.

This means that:




1. Faults which have been attended to or have disappeared are automatically erased.
2. Faults which have not been attended to must be acknowledged every time the system voltage is switched on.

Fault register



⚠ WARNING! Read the safety precautions for maintenance and service in the "Safety information" chapter before starting work.


Explanation



Faults are presented with information about reason and proposed measures to be taken.

1.	2.	3.	4.
Description	 R		
Explanation:			
Reaction:			
Action:			

1. Description of current fault and measures to take.
2. Current warning lamp which flashes during an alarm. O/R means that an orange or red lamp flashes.
3. Audible warning
4. Current fault pop-up which is shown on the EVC tachometer display.

Engine speed	 R	
Explanation: Fault in engine speed sensor.		⚠ DANGER! ENGINE SPEED SEE OP MANUAL
Reaction: Engine power is reduced.		
Action:		
<ul style="list-style-type: none"> • Please contact a Volvo Penta workshop. 		

Water in fuel	 O
Explanation: Water in water trap in fuel filters.	⚠ CAUTION! WATER IN FUEL SEE OP MANUAL
Reaction: None	
Action:	
<ul style="list-style-type: none"> • Empty the water trap underneath the fuel filters, please refer to "Maintenance: Fuel system". • Please contact a Volvo Penta workshop if the fault remains. 	

Seawater pressure	 R	
Explanation: Seawater pressure too low.	⚠ WARNING! SEA WATER PRESS. SEE OP MANUAL	
Reaction: Engine power is reduced.		
Action:		
<ul style="list-style-type: none"> • Check that the seawater filter is not blocked. Please refer to "Maintenance: Seawater system". • Check the impeller in the sea water pump. Please refer to "Maintenance: Seawater system". • Check that no leakage occurs. • Please contact a Volvo Penta workshop if the fault remains. 		

Air temperature**Explanation: Charge air temperature too high.****Reaction:** Engine power is reduced.**Action:**

- Please contact a Volvo Penta workshop.

**Coolant level****Explanation: Coolant level too low.****Reaction:** Engine power is reduced.**Action:**

- Check coolant level. Please refer to "Maintenance: Freshwater system".
- Check that no leakage occurs in auxiliary equipment connected to the engine cooling system.
- Please contact a Volvo Penta workshop if the fault remains.

**Coolant pressure****Explanation: Coolant pressure too low.****Reaction:** Engine power is reduced.**Action:**

- Check the coolant level. Please refer to "Maintenance: Freshwater system".
- Check that the seawater filter is not blocked. Please refer to "Maintenance: Seawater system".
- Check the impeller in the seawater pump. Please refer to "Maintenance: Seawater system".
- Check that no leakage occurs.
- Check that no leakage occurs in auxiliary equipment connected to the engine cooling system.
- Please contact a Volvo Penta workshop if the fault remains.

**Coolant temperature****Explanation: Ccoolant temperature too high.****Reaction:** Engine power is reduced.**Action:**

- Check coolant level. Please refer to "Maintenance: Fresh water system".
- Check that the seawater filter is not blocked. Please refer to "Maintenance: Seawater system".
- Check the impeller in the seawater pump. Please refer to "Maintenance: Seawater system".
- Check that no leakage occurs.
- If the cooling water flow ceases, the exhaust hose should be inspected internally and replaced if the hose shows signs of damage.
- Please contact a Volvo Penta workshop if the fault remains.



Fuel pressure



Explanation: Fuel pressure too low.

Reaction: Engine power is reduced.

Action:

- Check the fuel level.
- Open the fuel taps and check that no leakage occurs.
- Check that the fuel filters are not blocked. Please refer to "Maintenance: Fuel system"
- Please contact a Volvo Penta workshop if the fault remains.



Fuel temperature



Explanation: Fuel temperature too high.

Reaction: Engine power is reduced.

Action:

- Check the fuel level.
- Check fuel cooler.
- Check that no leakage occurs.
- Please contact a Volvo Penta workshop if the fault remains.



Engine oil level



Explanation: Oil level too low.

NOTE! In rough following seas or head seas, the system can incorrectly sense that the engine oil level is too low. If this happens, acknowledge the fault, and check the points below for safety reasons.

Reaction: Engine power is reduced.

Action:

- Check the oil level in the engine. Please refer to "Maintenance: Lubrication system" to check and top the oil up.
- Check the oil filters. Please refer to "Maintenance: Lubrication system".
- Check that no leakage occurs.
- Please contact a Volvo Penta workshop if the fault remains.



Engine oil pressure



Explanation: Oil pressure too low.

Reaction: Engine power is reduced.

Action:

- Check the oil level in the engine. Please refer to "Maintenance: Lubrication" to check and top the oil up.
- Check that the oil filters are not blocked.
- Check that no leakage occurs.
- Please contact a Volvo Penta workshop if the fault remains.



Engine oil temperature**Explanation:** Engine oil temperature too high.**Reaction:** Engine power is reduced.**Action:**

- Check the oil level. Please refer to "Maintenance: Lubrication system".
- Check that the oil filters are not blocked. Please refer to "Maintenance: Lubrication system".
- Check that no leakage occurs.
- Please contact a Volvo Penta workshop if the fault remains.

**Engine oil filter****Explanation:** Oil pressure differential too big.**Reaction:** Engine power is reduced.**Action:**

- Check that the oil filters are not blocked. Please refer to "Maintenance: Lubrication system".
- Please contact a Volvo Penta workshop if the fault remains.

**Crankcase pressure****Explanation:** Crankcase pressure too high.**Reaction:** Engine power reduced.**Action:**

- Check that the crankcase ventilation is not blocked. Please refer to "Maintenance: Engine, general".
- Please contact a Volvo Penta workshop if the fault remains.

**Exhaust temperature****Explanation:** Exhaust temperature too high.**Reaction:** Engine power is reduced.**Action:**

- Please contact a Volvo Penta workshop.

**Transmission oil pressure****Explanation:** Transmission oil pressure too low.**Reaction:** Engine power is reduced.**Action:**

- Check oil level. Please refer to "Maintenance: Lubrication system".
- Check that the oil strainer is not blocked. Please refer to "Maintenance: Lubrication system".
- Check that no leakage occurs.
- Please contact a Volvo Penta workshop if the fault remains.



Battery voltage



Explanation: Battery voltage too low.

Reaction:

Action:

- Check battery fluid level.
- Check belt tension.
- Please contact a Volvo Penta workshop if the fault remains.



Auxiliary stop



Explanation: External stop signal.

Reaction: Engine stops or can not be started

Action:

- Check emergency stop button. Reset if necessary. Please refer to "Stopping the engine: Emergency stop"
- Please contact a Volvo Penta workshop if the fault remains.



Primary battery



Explanation: Poor battery or charging.

Reaction:

Action:

- Check battery fluid level.
- Check belt tension.
- Please contact a Volvo Penta workshop if the fault remains.



Secondary battery



Explanation: Poor battery or charging.

Reaction:

Action:

- Check battery fluid level.
- Check belt tension.
- Please contact a Volvo Penta workshop if the fault remains.



30 V supply fuse



Explanation: Fuse is broken.

Reaction:

Action:

- Please contact a Volvo Penta workshop.



EMS supply fuse  R 

Explanation: Fuse is broken.

Reaction:

Action:

- Please contact a Volvo Penta workshop.



Extra supply fuse  R 

Explanation: Fuse is broken.

Reaction:

Action:

- Please contact a Volvo Penta workshop.



Check control lever  O/R 

Explanation: Fault in control lever.

Reaction: Engine in emergency mode. Gear to neutral.

Action:

- Restart engine(s).
- If the engine can not be operated from the chosen control panel, use an alternative control panel.
- Please contact a Volvo Penta workshop if the fault remains.



Lever calibration  O

Explanation: Incorrect lever calibration.

Reaction: It is not possible to choose active helm station.

Action:

- Restart engine(s).
- Please contact a Volvo Penta workshop if the fault remains.



Check EVC system  O/R 

Explanation: Internal fault in the EVC system.

Reaction: Engine power is reduced.

Action:

- Restart engine(s).
- If the engine can not be operated from the chosen control panel, use an alternative control panel.
- Please contact a Volvo Penta workshop if the fault remains.



System failure



R



Explanation: Miscellaneous fault.

Reaction:

Action:

- Restart engine(s).
- Please contact a Volvo Penta workshop if the fault remains.



Check joystick



O/R



Explanation: Fault in joystick.

Reaction: Engine power is reduced.

Action:

- Restart engine(s).
- If the engine can not be operated from the chosen control panel, use an alternative control panel.
- Please contact a Volvo Penta workshop if the fault remains.



Check steering wheel



O

Explanation: Fault in steering wheel unit.

Reaction: Engine power is reduced.

Action:

- Restart both engines.
- Please contact a Volvo Penta workshop if the fault remains.



Limited engine rpm



R



Explanation: Fault in steering system.

Reaction: Engine power is reduced on both sides.

Action:

- Restart both engines.
- Please contact a Volvo Penta workshop if the fault remains.



Limited steering



R



Explanation: Fault in steering system.

Reaction: Engine power is reduced on both sides. Limited steering.

Action:

- Restart both engines.
- Please contact a Volvo Penta workshop if the fault remains.



No steering wheel response

R

**Explanation: Fault in steering wheel unit.****Reaction:** Engine power is reduced on both sides. No steering.**Action:**

- Restart both engines.
- Please contact a Volvo Penta workshop if the fault remains.

**No gear/throttle and steering**

R

**Explanation: Fault in steering system.****Reaction:** No steering. No propulsion.**Action:**

- Restart both engines.
- Please contact a Volvo Penta workshop if the fault remains.



Technical data

Engine model

Engine model.....	D12-300	D12-350	D12-400
Crankshaft power @ 1800 rpm, kW (hp)	216 (294)	256 (348)	294 (400)
Max. torque @ 1000 rpm, Nm (lbf.ft)	1461 (1078)		
Max. torque @ 1200 rpm, Nm (lbf.ft)		1592 (1174)	1814 (1338)
Max. torque @ 1400 rpm, Nm (lbf.ft)			
Engine model.....	D12-450	D12-500	D12-550
Crankshaft power @ 1800 rpm, kW (hp)	331 (450)	367 (499)	
Crankshaft power @ 1900 rpm, kW (hp)			405 (550)
Max. torque @ 1200 rpm, Nm (lbf.ft)		2204 (1626)	2196 (1620)
Max. torque @ 1400 rpm, Nm (lbf.ft)	2019 (1489)		

General

After market designation	D12D-C MH
No. of cylinders and configuration.....	in-line 6
Bore/stroke	131/150 mm (5.16/5.91in)
Displacement.....	12.13 l (740 in ³)
Compression ratio	17.5:1
Dry weight bobtail.....	1400 kg (3086 lb)
Dry weight with reverse gear MG5114SC	1603 kg (3534 lb)
Low idle speed.....	525 (±10) rpm*

* At delivery, the idling speed is adjusted to 520 rpm.

If needed, the speed can be adjusted within the range 550–700 rpm (refer to page).

Technical data according to ISO 8665.

Fuel system

Fuel specification

The fuel must comply with national and international standards for commercially supplied fuels, such as:

EN 590 (with national environment and cold requirements)

ASTM D 975 No 1-D and 2-D

JIS KK 2204


Sulfur content: Complying with legal requirements in each country.

Low density fuel (urban diesel in Sweden and city diesel in Finland) can cause a loss of up to 5% of power and an increase in fuel consumption of about 2–3%.

Lubricating system

Oil capacity including oil filters, approx., no engine inclination.....	56 liters (11.6 US gals)
Oil pressure, hot engine, at normal running rpm	400–550 kPa (57–80 psi)
at idling rpm (min.)	175 kPa (25.3 psi)
Oil grade	Refer to specification on page 57

Viscosity at different outside air temperatures
(Temperature based on constant outside air
temperature.



* Refers to synthetic or semi-synthetic oil.

Cooling system

Freshwater system capacity including heat exchanger, approx.	60 liters (15.9 US gals)
--	--------------------------

Electrical system

System voltage	24V
AC generator, voltage/max. amperage	28V/60A
output, approx.....	1700W
Alternative generator equipment (accessory): voltage/max. amperage	28V/100A
output, approx.....	2800W
Alternative generator equipment (accessory): voltage/max. amperage	14V/130A
output, approx.....	1820W
Battery capacity	2 connected in series 12V, max. 152Ah
Battery electrolyte density at +25°C (77°F): fully charged battery	1.28 g/cm ³ = 0.0462 lb/in ³ (1.24 g/cm ³ = 0.0448 lb/in ³)*
battery recharged at	1.24 g/cm ³ = 0.0448 lb/in ³ (1.20 g/cm ³ = 0.0434 lb/in ³)*

* **Note.** Applies to batteries with tropical acid.

Reverse gear

Twin Disc

Type designation	MG5114SC	MG5114DC
Oil capacity, approx.....	13 liters (3.4 US gals)	19,7 liters (5.2 US gals)
Oil grade (in accordance with API system).....	CC, CD, CE	CC, CD, CE
Viscosity at oil temperature 66–85°C	SAE30*	SAE30*
Viscosity at oil temperature 85–100°C	SAE40*	SAE40*
Oil pressure during ** Neutral.....	0,207–0,634 MPa (2,1–6,5 kp/cm ²)	0,207–0,634 MPa (2,1–6,5 kp/cm ²)
Oil pressure during ** operation	1,57–1,63 MPa (16–16,6 kp/cm ²)	1,57–1,63 MPa (16–16,6kp/cm ²)
Weight, approx.....	213 kg (470 lbs)	374 kg (825 lbs)

* **NOTE!** Only **single grade** lubricating oil (only **one** viscosity number) may be used in the reverse gear.

** At oil temperature 82°C and 1800 rpm.

Clutch

Disengageable clutches at front of engine (accessory)

Twin Disc

Type	Twin disc clutch (“over-center” type)
Gear ratio.....	1:1
Size.....	292 mm (11 ½”)
Permitted engine speed with PTO engaged	900–1800 rpm.
Max. permitted torque output.....	514 Nm (379 lbf.ft.)
Weight, approx.....	78 kg (172 lbs)

Notes

A series of horizontal dotted lines for writing notes.

ENG

Post or fax this coupon to:
Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Sweden
Fax: +46 31 545 772

Orders can also be placed via
the Internet:
[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Yes please,

I would like an operator's manual in English at no charge.

Publication number: 7746214

Name

Address

Country

*NB! This offer is valid for a period of 12 months from delivery of the boat.
Availability after this period will be as far as supplies admit.*

**VOLVO
PENTA**

42200/615001/155099900192

GER

Schicken Sie den Coupon
per Post oder als Fax an:
Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Schweden
Fax: +46 31 545 772

Die Bestellung kann auch über
das Internet erfolgen:
[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Ja,

ich will kostenlos eine Betriebsanleitung in deutscher Sprache erhalten.

Publikationsnummer: 7746216

Name

Anschrift

Land

*Bitte beachten Sie, dass dieses Angebot für die Dauer von 12 Monaten ab dem
Lieferdatum des Bootes gilt, danach bis zum Aufbrauchen des Lagerbestandes.*

**VOLVO
PENTA**

42200/615001/155099900192

FRE

Envoyez ou faxez le bon de
commande à:
Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Suède
Fax: +46 31 545 772

Vous pouvez également pas-
ser la commande par Internet:
[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Oui merci,

Je souhaite recevoir un manuel d'instructions gratuit en français.

Numéro de publication: 7746217

Nom

Adresse

Pays

*Notez que l'offre est valable pendant 12 mois à partir de la date de livrai-
son du bateau, ensuite seulement en fonction des stocks disponibles.*

**VOLVO
PENTA**

42200/615001/155099900192

SPA

Franquear o enviar fax a:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Suecia
Fax: +46 31 545 772

El pedido puede hacerse también por internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Sí gracias,

deseo recibir gratuitamente un libro de instrucciones en español.

Número de publicación: 7746218

Nombre

Dirección

País

Nótese que el ofrecimiento vale durante 12 meses después de la fecha de entrega de la embarcación, y posteriormente solamente mientras duren las existencias.

**VOLVO
PENTA**

42200/615001/155099900192

ITA

Spedire il tagliando per posta o per fax a:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Svezia
Fax: +46 31 545 772

L'ordinazione può essere fatta anche su Internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Sì, grazie,

desidero ricevere gratuitamente un manuale d'istruzioni in lingua italiana.

Public. No.: 7746219

Nome e Cognome

Indirizzo

Paese

Si ricorda che l'offerta è valida per 12 mesi dalla data di consegna dell'imbarcazione; dopo il suddetto periodo l'offerta resta valida solo in base alla disposizione della pubblicazione in oggetto.

**VOLVO
PENTA**

42200/615001/155099900192

SWE

Posta eller faxes kupongen till:

Dokument & Distribution center
Ordermottagningen
ARU2, Avd. 64620
SE-405 08 Göteborg
Sverige
Fax: +46 31 545 772

Beställningen kan även göras via internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Ja tack,

jag vill kostnadsfritt ha en instruktionsbok på svenska.

Publikationsnummer: 7746215

Namn

Adress

Land

Observera att erbjudandet gäller i 12 månader från båtens leveransdatum, därefter endast i mån av tillgång.

**VOLVO
PENTA**

42200/615001/155099900192

DUT

Stuur of fax de coupon naar:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Zweden
Fax: +46 31 545 772

U kunt ook bestellen via internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Ja graag,

Ik wil kosteloos een instructieboek in het Nederlands ontvangen.

Publicatienummer: 7746224

Naam

Adres

Land

Denk eraan dat het aanbod geldt gedurende 12 maanden na de datum waarop de boot werd afgeleverd, daarna alleen indien nog verkrijgbaar.

**VOLVO
PENTA**

42200/615001/155099900192

DAN

Send kuponen med post eller fax til:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Sverige
Fax: +46 31 545 772

Bestillingen kan også ske på internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Ja tak,

jeg vil gerne gratis have en instruktionsbog på dansk

Publikationsnummer: 7746221

Navn

Adresse

Land

Bemærk at tilbudet gælder i 12 måneder fra bådens leveringsdato, Derefter kun så længe lager haves.

**VOLVO
PENTA**

42200/615001/155099900192

FIN

Postita tai faksaa kuponki osoitteella:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Ruotsi
Fax: +46 31 545 772

Tilauksen voi tehdä myös Internetissä:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Kyllä kiitos,

haluan suomenkielisen ohjekirjan veloituksetta.

Julkaisunumero: 7746222

Nimi

Osoite

Maa

Huomaa, että tarjous on voimassa 12 kuukautta veneen toimituspäivämäärästä lukien ja sen jälkeen vain niin kauan kuin kirjoja riittää.

**VOLVO
PENTA**

42200/615001/155099900192

POR

Envie o talão pelo correio ou um fax para:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Sweden
Fax: +46 31 545 772

A encomenda também pode ser feita através da Internet:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Sim, obrigado(a)!

Gostaria de receber gratuitamente um manual de instruções em português.

Número de publicação: 7746225

Nome

Endereço

País

Observar que esta oferta é válida durante um período de 12 meses a contar da data de entrega do barco. Após este período, a oferta está dependente do número de exemplares disponíveis.

**VOLVO
PENTA**

42200/615001/155099900192

GRE

Ταχυδρομήστε αυτό το κουπόνι στην παρακάτω διεύθυνση ή στείλτε το με φαξ στον παρακάτω αριθμό φαξ:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Sweden
Fax: +46 31 545 772

Μπορείτε επίσης να δώσετε την παραγγελία σας μέσω του Internet, στη διεύθυνση:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Ναι,

Θα ήθελα ένα αντίτυπο του εγχειριδίου χρήσης στην αγγλική γλώσσα χωρίς καμιά χρέωση.

Αριθμός έκδοσης: 7746223

Όνομα

Διεύθυνση

Χώρα

ΠΡΟΣΟΧΗ: Αυτή η προσφορά ισχύει για χρονική περίοδο 12 μηνών από την παράδοση του σκάφους. Μετά το πέρας της εν λόγω χρονικής περιόδου η διαθεσιμότητα των αντιτύπων θα εξαρτάται από την ποσότητα των αποθεμάτων.

**VOLVO
PENTA**

42200/615001/155099900192

RUS

Отправьте этот талон почтой или факсом на имя:

Document & Distribution Center
Order Department
ARU2, Dept. 64620
SE-405 08 Göteborg
Sweden
Fax: +46 31 545 772

Заказы также можно размещать через Интернет:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Да, пожалуйста,

Я бы хотел иметь бесплатное руководство оператора на русском языке.

Номер издания: 7746226

Имя

Адрес

Страна

К Вашему сведению, это предложение действительно в течение 12 месяцев от даты поставки двигателя; в дальнейшем оно зависит от наличия.

**VOLVO
PENTA**

42200/615001/155099900192

TUR

**Bu kuponu þu adrese posta-
layın veya fakslayın:**

Dokument & Distribution center
Ordermottagningen
ARU2, Avd. 64620
SE-405 08 Göteborg
Ýsveç
Faks: +46 31 545 772

Siparişler Ýnternet üzerinden de
verilebilir:

[http://www.volvopenta.com/
manual/coupon](http://www.volvopenta.com/manual/coupon)

Evet lütfen,

ücretsiz Türkçe kullanım el kitabý istiyorum

Yayın numarasý: 7746227

Ýsim

Adres

Ülke

*NB! Bu teklif, tekenin teslim edilmesinden itibaren 12 aylık bir süre için
geçerlidir. Bu süre sonunda ürün dađıtýmý stoklarla sınırlýdır.*

**VOLVO
PENTA**

42200/615001/155099900192

